

**General Standards Corporation
SIO4 Application Interface
For LabView© Users Manual
V1.2.9**

April 14, 2006

Table of Contents

Introduction.....	4
Installation.....	4
Project Setup	6
System Level Routines	7
GscSio4FindBoards	7
GscSio4GetErrorString	8
Board Level Routines	9
GscSio4Open	9
GscSio4Close	10
GscSio4GetVersions	11
GscSio4LocalRegisterRead	12
GscSio4LocalRegisterWrite	13
Channel Level Routines.....	14
GscSio4ChannelReset.....	14
GscSio4ChannelResetRxFifo	15
GscSio4ChannelResetTxFifo.....	16
GscSio4ChannelRegisterRead	17
GscSio4ChannelRegisterWrite	18
GscSio4ChannelSetMode / GscSio4ChannelGetMode	19
GscSio4ChannelSetDataSize / GscSio4ChannelGetDataSize	21
GscSio4ChannelSetGapSize / GscSio4ChannelGetGapSize.....	22
GscSio4ChannelSetMsbLsbOrder / GscSio4ChannelGetMsbLsbOrder.....	23
GscSio4ChannelSetParity / GscSio4ChannelGetParity.....	24
GscSio4ChannelSetStopBits / GscSio4ChannelGetStopBits	25
GscSio4ChannelSetEncoding / GscSio4ChannelGetEncoding	26
GscSio4ChannelSetProtocol / GscSio4ChannelGetProtocol.....	27
GscSio4ChannelSetDteDce / GscSio4ChannelGetDteDce	29
GscSio4ChannelSetLoopBack / GscSio4ChannelGetLoopBack	30
GscSio4ChannelSetPinMode / GscSio4ChannelGetPinMode	31
GscSio4ChannelSetPinValue / GscSio4ChannelGetPinValue	32
GscSio4ChannelFifoSizes.....	33
GscSio4ChannelFifoCounts.....	34
GscSio4ChannelSetTxAlmost / GscSio4ChannelGetTxAlmost	35
GscSio4ChannelSetRxAlmost / GscSio4ChannelGetRxAlmost.....	36
GscSio4ChannelCheckForData	37
GscSio4ChannelReceiveData	38
GscSio4ChannelReceiveDataAndWait.....	39
GscSio4ChannelTransmitData.....	40
GscSio4ChannelTransmitDataAndWait	41
GscSio4ChannelQueryTransfer	42
GscSio4ChannelWaitForTransfer.....	43
GscSio4ChannelFlushTransfer	44
GscSio4ChannelRemoveTransfer.....	45
GscSio4ChannelRegisterInterrupt	46

GscSio4ChannelSetClock	47
GscSio4ChannelSetClockSource	48
Protocol Level Routines.....	49
GscSio4ChannelSetHdlcCrcMode / GscSio4ChannelGetHdlcCrcMode	49
GscSio4ChannelSetBiSyncPattern / GscSio4ChannelGetBiSyncPattern.....	51
Structures and Macro Definitions	52
Devices Structure	52
Interrupt Callback Prototype.....	52
Channel Mode Definitions.....	53
Channel Encoding Definitions.....	54
Channel Protocol and Termination Definitions	55
Channel Interrupt Definitions	56
Channel Pin Definitions.....	57
Channel Parity Definitions.....	58
Channel Stop Bits Definition	59
Loopback Definitions.....	59
HDLC CRC Defintions.....	59
Local Register Definitions	60
Channel Register Definitions.....	61
Miscellaneous Token Definitions	62

Introduction

This document describes the Application Programmers Interface (API) for the General Standards Corporation I/O Interface boards. Some API functions apply only to certain hardware. Each function contains the list of boards that it supports. For examples of how to use the API functions, refer to the source code included in the API examples.

This API was written using Microsoft Visual C++ 6.0 and is compatible with both Win32 and MFC applications. The 'C' version and LabView both use the same GscApi.dll file.

Installation

The API support files are installed during the standard installation of the driver. The API support files are placed, by default, into the "C:\Program Files\General Standards Corporation\GscApiLabView\" directory and subdirectories and consist of the following files:

plxsw-sio4b-labview-sample-test_v1.vi – This is a sample LabView test that allows the user to get a basic understanding of the GscApiLabView interface and how to use it to perform a simple loopback type test on the SIO4B/BX.

plxsw-sio4b-labview-sample-test_v2.vi – Another sample LabView test that allows the user to get a basic understanding of the GscApiLabView interface and how to use it to perform a simple loopback type test on the SIO4B/BX.

sio4b.bx_sync_labview_v1.vi – Sample test application specific to the SIO4B-SYNC or SIO4BX-SYNC cards only. This test will not operate properly with a non-SYNC version of the cards. Please use one of the tests above for those cards.

GscApiLabView.llb – This is the LabView library file that contains VIs for all the API functions.

GscApi.dll – This is the dynamically linked library file that contains the actual API code. It should be located in the same directory as your executable or in your system path so that your application can access the API functions. This file will also be installed to your system32 directory during installation.

It is recommended that you install the driver/API before installing the SIO4B/BX card. After the installation completes, shut the system down and install the SIO4B/BX card.

Under Windows XP, you may get the following warning during the Hardware Wizard's installation of the card. You can safely choose Continue Anyway to install the driver.



Project Setup

Copy the GscApiLabView folder (and all its contents) from the directory:
Typically “\Program Files\General Standards Corporation\”

To the <inst.lib> folder where Labview is installed.
Typically: “\Program Files\National Instruments\LabView 7.0\inst.lib\”

When LabView is started, it will automatically add the SIO4 menu to the Functions palette, Instrument I/O sub-palette.

You can run the simple sample test provided to get a idea of the interface used by the GscApiLabView interface. This sample test provides a simple loopback type test to verify operation of the hardware and driver installation. It is also provided to give the user a simple overview of the GscApiLabView interface.

To use the test to send data from one channel to another, a "gender-changer" must be used between the two channels under test. You can choose the same channel for both transmit and receive and an external loop-back test on a single channel will be performed. For the single channel test, it is best to leave all cables disconnected from the card.

This test was written to allow testing using some of the simpler serial protocols such as asynchronous and HDLC. Use of other protocols besides these will require modification to this test in order for proper operation.

There are a number of data values defined for specific modes and protocols for use by the GscApi.dll file. Copies of LabView ring enumerations for these defines are located in the GscSio4Defines.vi file in the GscApiLabView.llb LabView library.

System Level Routines

The System Level Routines perform functions that either apply to all SIO4 boards in the system, or are not board specific. These routines are used to gather information about the current system setup. All of these functions return zero if successful or a non-zero error code if a failure occurs.

GscSio4FindBoards

Due to differences in the handling of data structures between 'C' and LabView, the GscSio4FindBoards() function is depreciated in favor of using the GscSio4Open() function in conjunction with the GscSio4GetVersions() function instead.

Supported Hardware:

N/A

Prototype:

N/A

Parameters:

N/A

GscSio4GetErrorString

`GscSio4GetErrorString(...)` is used to translate the error codes that are returned by the various API functions into meaningful null-terminated strings. The strings returned by this function are guaranteed to be less than 80 characters in length.

Supported Hardware:

All

Prototype:

```
int GscSio4GetErrorString(  
                                int errorCode,  
                                char *errorString);
```

Parameters:

errorCode – the error code returned by an API function.

errorString – a pointer to a character string that will be filled with the text that corresponds to the *errorCode*.

Board Level Routines

The Board Level Routines perform functions that apply to a single SIO4 board. These functions affect all channels of the SIO4 board. Each of these routines requires the board number (*boardNumber*) as the first argument. The board numbers run from 1 up to the number that is returned from the call to `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

These routines can be called at any time. All of these functions return zero if successful or a non-zero error code if a failure occurs.

GscSio4Open

`GscSio4Open(...)` is used to “open” the SIO4 board for operation. It should be called before any other Board or Channel Level routines and should only be called once. In the process of opening a board, all four channels are reset and the clock outputs are disabled.

Supported Hardware:

All

Prototype:

```
int GscSio4Open( int boardNumber);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

GscSio4Close

`GscSio4Close(...)` is used to “close” the SIO4 board. It should be the last API function called before the application terminates. This function releases the resources that are used by the API and driver.

Supported Hardware:

All

Prototype:

```
int GscSio4Close( int boardNumber);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

GscSio4GetVersions

GscSio4GetVersions(...) returns the various version numbers associated with the API, the low level driver, and the SIO4 board's FPGA. The Library and Driver version numbers are returned in the form: 0x00MMmmee where MM is the major release number, mm is the minor release number, and ee is the engineering release number. The entire version is defined as MM.mm.ee for example 1.02.05 is returned as 0x00010205. The FPGA version number has several encoded fields. The low byte contains the actual version number. Refer to the hardware users manual for details on the other encoded fields.

Supported Hardware:

All

Prototype:

```
int GscSio4GetVersions(  
    int boardNumber,  
    int *libVersion,  
    int *driverVersion,  
    int *fpgaVersion);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

libVersion – A pointer to the location that will receive the library (API) version number. If this value is NULL, no value will be returned.

driverVersion – A pointer to the location that will receive the low level driver version number. If this value is NULL, no value will be returned.

fpgaVersion – A pointer to the location that will receive the FPGA firmware version number. If this value is NULL, no value will be returned.

GscSio4LocalRegisterRead

GscSio4LocalRegisterRead(...) is used to read the local board registers. These registers reside within the board's FPGA. It is not recommended that a user application directly access these registers. This function is included for diagnostic purposes only.

Supported Hardware:

All

Prototype:

```
int GscSio4LocalRegisterRead(  
                                int boardNumber,  
                                int reg,  
                                int *result);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

reg – The address of the register to be read. Macros for these addresses are described in the section titled “Local Register Definitions”.

result – A pointer to the location that will receive the results of the read operation.

GscSio4LocalRegisterWrite

`GscSio4LocalRegisterWrite(...)` is used to write to the local board registers. These registers reside within the board's FPGA. It is not recommended that a user application directly access these registers. This function is included for diagnostic purposes only.

Supported Hardware:

All

Prototype:

```
int GscSio4LocalRegisterWrite(  
                                int boardNumber,  
                                int reg,  
                                int value);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

reg – The address of the register to be written. Macros for these addresses are described in the section titled “Local Register Definitions”.

value – The value that is to be written to the local register.

Channel Level Routines

The Channel Level Routines perform functions that apply to a single channel on an SIO4 board. Each of these routines requires the board number (`boardNumber`) as the first parameter and the channel number (`channel`) as the second parameter. The board number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system. The channel number will always be 1, 2, 3, or 4.

These routines can be called at any time. All of these functions return zero if successful or a non-zero error code if a failure occurs.

GscSio4ChannelReset

`GscSio4ChannelReset(...)` resets a single channel on the SIO4 board. In addition to disabling the serial channel, this function sets the “Almost Empty” and “Almost Full” FIFO flags to 16.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelReset(  
                        int boardNumber,  
                        int channel);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

GscSio4ChannelResetRxFifo

`GscSio4ChannelResetRxFifo(...)` resets the Rx FIFO for a single channel. After the reset, the FIFO will contain no data.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelResetRxFifo (  
                                int boardNumber,  
                                int channel);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

GscSio4ChannelResetTxFifo

`GscSio4ChannelResetTxFifo(...)` resets the Tx FIFO for a single channel. After the reset, the FIFO will contain no data.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelResetTxFifo (  
                                int boardNumber,  
                                int channel);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

GscSio4ChannelRegisterRead

`GscSio4ChannelRegisterRead(...)` is used to read the registers in the Universal Serial Chip that controls the specified channel. It is not recommended that a user application directly access these registers. This function is included for diagnostic purposes only.

Supported Hardware:

PCI-SIO4B

Prototype:

```
int GscSio4ChannelRegisterRead(  
                                int boardNumber,  
                                int channel,  
                                int reg,  
                                int *value);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

reg – The address of the register to be read. Macros for these addresses are described in the section titled “Channel Register Definitions”.

value – A pointer to the location that will receive the results of the read operation.

GscSio4ChannelRegisterWrite

`GscSio4ChannelRegisterWrite(...)` is used to write to the registers in the Universal Serial Chip that controls the specified channel. It is not recommended that a user application directly access these registers. This function is included for diagnostic purposes only.

Supported Hardware:

PCI-SIO4B

Prototype:

```
int GscSio4ChannelRegisterWrite(  
                                int boardNumber,  
                                int channel,  
                                int reg,  
                                int value);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

reg – The address of the register to be written. Macros for these addresses are described in the section titled “Channel Register Definitions”.

value – The value that is to be written to the register.

GscSio4ChannelSetMode / GscSio4ChannelGetMode

GscSio4ChannelSetMode(...) sets a single channel of the SIO4 board to the desired serial format and bit rate.

Each mode has its own defaults, as described below, which can be altered by calling the appropriate Channel Level Routines after this function returns.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelSetMode(  
                                int boardNumber,  
                                int channel,  
                                int mode,  
                                int bitRate);  
  
int GscSio4ChannelGetMode(  
                                int boardNumber,  
                                int channel,  
                                int *mode,  
                                int *bitRate);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

mode – The desired/current serial mode for this channel. The value should be one of the following:

GSC_MODE_ASYNC – Sets the channel to standard asynchronous mode. The channel defaults to 8 data bits, no Parity, and one stop bit. It also uses a 16x sampling clock.

GSC_MODE_ISO – Sets the channel to isochronous mode. Uses the same defaults as GSC_MODE_ASYNC except the sampling clock, which is set to 1x.

GSC_MODE_HDLC – Sets the channel to HDLC mode. The Transmit clock is derived from the on-board source at the rate specified (*bitRate*) and is also driven onto the cable for use by the receiving end. The receiver clock is

connected to the cable and should be supplied by the transmitter at the other end.

GSC_MODE_SYNC -
GSC_MODE_SYNC_ENV – (SIO4-SYNC boards only)
GSC_MODE_ASYNC_CV -
GSC_MODE_MONOSYNC -
GSC_MODE_BISYNC -
GSC_MODE_TRANS_BISYNC –

GSC_MODE_NBIF -
GSC_MODE_802_3 -

bitRate – The desired/current serial bit (baud) rate for this channel. This value can range from 250 to 10,000,000 for synchronous modes and 50 to 1,000,000 for asynchronous modes.

GscSio4ChannelSetDataSize / GscSio4ChannelGetDataSize

`GscSio4ChannelSetDataSize(...)` sets the size of the transmitted and received data for a single channel of the SIO4 board. The data size can be set to any value between 1 and 8 inclusive on the standard SIO4 boards. The data size can be set to any value between 1 and 65535 on the –SYNC boards.

Supported Hardware:

ALL

Prototype:

```
int GscSio4ChannelSetDataSize(  
                                int boardNumber,  
                                int channel,  
                                int dataSize);  
  
int GscSio4ChannelGetDataSize(  
                                int boardNumber,  
                                int channel,  
                                int *dataSize);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

dataSize – The desired/current data size for this channel. The value should be between 1 and 8 on the standard boards and between 1 and 65535 on the -SYNC boards.

GscSio4ChannelSetGapSize / GscSio4ChannelGetGapSize

`GscSio4ChannelSetGapSize(...)` sets the size of the gap between transmitted data words for a single channel of the SIO4 board. The gap size can be set to any value between 0 and 65535.

Supported Hardware:

SIO4-SYNC

Prototype:

```
int GscSio4ChannelSetGapSize(  
                                int boardNumber,  
                                int channel,  
                                int gapSize);
```

```
int GscSio4ChannelGetGapSize(  
                                int boardNumber,  
                                int channel,  
                                int *gapSize);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

gapSize – The desired/current gap size for this channel. The value should be between 1 and 65535.

GscSio4ChannelSetMsbLsbOrder / GscSio4ChannelGetMsbLsbOrder

GscSio4ChannelSetMsbLsbOrder(...) sets the order that the bits are shifted out onto the “wire”.

Supported Hardware:

SIO4-SYNC

Prototype:

```
int GscSio4ChannelSetGapSize(  
                                int boardNumber,  
                                int channel,  
                                int txOrder,  
                                int rxOrder);
```

```
int GscSio4ChannelGetGapSize(  
                                int boardNumber,  
                                int channel,  
                                int *txOrder,  
                                int *rxOrder);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

txOrder – The desired/current MSB/LSB ordering for the transmitter. The valid values are either GSC_MSB_FIRST or GSC_LSB_FIRST.

rxOrder – The desired/current MSB/LSB ordering for the receiver. The valid values are either GSC_MSB_FIRST or GSC_LSB_FIRST.

GscSio4ChannelSetParity / GscSio4ChannelGetParity

GscSio4ChannelSetParity(...) sets the type of parity that will be used on a single channel of the SIO4 board. The parity can be set to None, Even Odd, Space, or Mark.

Supported Hardware:

PCI-SIO4B

Prototype:

```
int GscSio4ChannelSetParity(  
    int boardNumber,  
    int channel,  
    int parity);  
  
int GscSio4ChannelGetParity(  
    int boardNumber,  
    int channel,  
    int *parity);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

parity – The desired/current parity type for this channel. The value should be one of the following:

GSC_PARITY_NONE – Sets the channel to no parity.

GSC_PARITY_EVEN – Sets the channel to Even parity.

GSC_PARITY_ODD – Sets the channel to Odd parity.

GSC_PARITY_MARK - Sets the channel to Mark parity.

GSC_PARITY_SPACE - Sets the channel to Space parity.

GscSio4ChannelSetStopBits / GscSio4ChannelGetStopBits

GscSio4ChannelSetStopBits(...) sets the number of stop bits to use for a single channel of the SIO4 board. The number of stop bits can be set to 0, 1, 1 ½, or 2 bits.

Supported Hardware:

PCI-SIO4B

Prototype:

```
int GscSio4ChannelSetStopBits(  
                                int boardNumber,  
                                int channel,  
                                int stopBits);
```

```
int GscSio4ChannelGetStopBits(  
                                int boardNumber,  
                                int channel,  
                                int *stopBits);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

stopBits – The desired/current number of stop bits for this channel. The value should be one of the following:

GSC_STOP_BITS_0 – Sets the channel to no stop bits. This setting can only be used when the channel is set to Async with Code Violation (MIL STD 1553) mode.

GSC_STOP_BITS_1 – Sets the channel to 1 stop bit.

GSC_STOP_BITS_1_5 – Sets the channel to 1 ½ stop bits.

GSC_STOP_BITS_2 – Sets the channel to 2 stop bits.

GscSio4ChannelSetEncoding / GscSio4ChannelGetEncoding

GscSio4ChannelSetEncoding(...) sets the encoding type for a single channel of the SIO4 board. The encoding can be set to NRZ, NRZB, NRZI Mark, NRZI Space, Biphasic Mark, Biphasic Space, Biphasic Level, or Differential Biphasic Level on standard boards. The encoding can be set to only NRZ or NRZB on the –SYNC boards.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelSetEncoding(  
                                int boardNumber,  
                                int channel,  
                                int encoding);  
  
int GscSio4ChannelGetEncoding(  
                                int boardNumber,  
                                int channel,  
                                int *encoding);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

encoding – The desired/current encoding type for this channel. This value should be one of the macros defined in the section “Channel Encoding Definitions”.

GscSio4ChannelSetProtocol / GscSio4ChannelGetProtocol

GscSio4ChannelSetProtocol(...) sets the physical interface protocol and termination options. The protocol on the standard SIO4B card is fixed at RS422/RS485 or RS232 depending on the configuration set at the factory. Only the –BX cards allow this value to be changed.

Supported Hardware:

PCI-SIO4B-BX

Prototype:

```
int GscSio4ChannelSetProtocol(  
                                int boardNumber,  
                                int channel,  
                                int protocol,  
                                int termination);  
  
int GscSio4ChannelGetProtocol(  
                                int boardNumber,  
                                int channel,  
                                int *protocol,  
                                int *termination);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

protocol – The desired/current physical interface protocol. The value can be any of the following:

- GSC_PROTOCOL_RS422_RS485 – Sets
- GSC_PROTOCOL_RS423 – Sets
- GSC_PROTOCOL_RS232 – Sets
- GSC_PROTOCOL_RS530_1 – Sets
- GSC_PROTOCOL_RS530_2 – Sets
- GSC_PROTOCOL_V35_1 – Sets
- GSC_PROTOCOL_V35_2 – Sets
- GSC_PROTOCOL_RS422_RS423_1 – Sets
- GSC_PROTOCOL_RS422_RS423_2 – Sets

termination – The desired/current termination setting. The value can be any of the following:

- GSC_TERMINATION_ENABLED – Sets
- GSC_TERMINATION_DISABLED – Sets

GscSio4ChannelSetDteDce / GscSio4ChannelGetDteDce

GscSio4ChannelSetDteDce(...) sets a single channel of the SIO4 board to either DTE or DCE mode. Each channel defaults to DTE mode when it is configured. Calling this routine is only necessary if DCE mode is required, or to switch back to DTE mode after a previous change to DCE mode.

The pin-outs for both DTE and DCE modes are available in the Hardware Users Manual.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelSetDteDce(
                                int boardNumber,
                                int channel,
                                int mode);

int GscSio4ChannelGetDteDce(
                                int boardNumber,
                                int channel,
                                int *mode);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

mode – The desired/current DTE/DCE mode for this channel. The value should be one of the following:

GSC_PIN_DTE – Sets the channel to DTE mode. See the hardware manual for the cable pin-out.

GSC_PIN_DCE - Sets the channel to DCE mode. See the hardware manual for the cable pin-out.

GscSio4ChannelSetLoopBack / GscSio4ChannelGetLoopBack

This function

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelSetLoopBack(  
                                int boardNumber,  
                                int channel,  
                                int loopMode);  
  
int GscSio4ChannelGetLoopBack(  
                                int boardNumber,  
                                int channel,  
                                int *loopMode);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

loopMode – The desired/current loopback mode.

GscSio4ChannelSetPinMode / GscSio4ChannelGetPinMode

GscSio4ChannelSetPinMode(...)

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelSetPinMode (  
                                int boardNumber,  
                                int channel,  
                                int pinName,  
                                int mode);  
  
int GscSio4ChannelGetPinMode (  
                                int boardNumber,  
                                int channel,  
                                int pinName,  
                                int *mode);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

GscSio4ChannelSetPinValue / GscSio4ChannelGetPinValue

GscSio4ChannelSetPinValue(...)

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelSetPinValue (  
                                int boardNumber,  
                                int channel,  
                                int pinName,  
                                int value);
```

```
int GscSio4ChannelGetPinValue (  
                                int boardNumber,  
                                int channel,  
                                int pinName,  
                                int *value);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

GscSio4ChannelFifoSizes

`GscSio4ChannelFifoSizes(...)` returns the size, in bytes, of the channel's Transmit and Receive FIFOs. The size of the Transmit FIFO is returned in the upper 16 bits and the size of the Receive FIFO is returned in the lower 16 bits of the result (*sizes*).

Supported Hardware:

PCI-SIO4B

Prototype:

```
int GscSio4ChannelFifoSizes(  
    int boardNumber,  
    int channel,  
    int *sizes);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

sizes – A pointer to the location that will receive the size (in bytes) of the Transmit (upper 16 bits) and the Receive (lower 16 bits) FIFOs

GscSio4ChannelFifoCounts

`GscSio4ChannelFifoCounts(...)` returns the current number of bytes in the channel's Transmit and Receive FIFOs. The number of bytes in the Transmit FIFO are returned in the upper 16 bits and the number of bytes in the Receive FIFO are returned in the lower 16 bits of the result (*counts*).

Supported Hardware:

PCI-SIO4B

Prototype:

```
int GscSio4ChannelFifoCounts(  
                                int boardNumber,  
                                int channel,  
                                int *counts);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

counts – A pointer to the location that will receive the number of bytes currently in the Transmit (upper 16 bits) and the Receive (lower 16 bits) FIFOs.

GscSio4ChannelSetTxAlmost / GscSio4ChannelGetTxAlmost

GscSio4ChannelSetTxAlmost(...) programs the “Almost Full” and “Almost Empty” registers in the Transmit FIFO for a single channel. Once the values are programmed, the FIFO will be reset to force the change to take effect. This will also clear the contents of the FIFO, so this command should be done before any data transfers occur.

Supported Hardware:

PCI-SIO4B

Prototype:

```
int GscSio4ChannelSetTxAlmost(  
                                int boardNumber,  
                                int channel,  
                                int almostValue);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

almostValue – The 32bit value that will be programmed into the Transmitter FIFO’s Almost Full (upper 16 bits) and Almost Empty (lower 16 bits) registers.

GscSio4ChannelSetRxAlmost / GscSio4ChannelGetRxAlmost

GscSio4ChannelSetRxAlmost(...) programs the “Almost Full” and “Almost Empty” registers in the Receive FIFO for a single channel. Once the values are programmed, the FIFO will be reset to force the change to take effect. This will also clear the contents of the FIFO, so this command should be done before any data transfers occur.

Supported Hardware:

PCI-SIO4B

Prototype:

```
int GscSio4ChannelSetRxAlmost(  
                                int boardNumber,  
                                int channel,  
                                int almostValue);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

almostValue – The 32bit value that will be programmed into the Receiver FIFO’s Almost Full (upper 16 bits) and Almost Empty (lower 16 bits) registers.

GscSio4ChannelCheckForData

`GscSio4ChannelCheckForData(...)` checks for the reception of a complete packet on the Channel's Receiver. If no complete packets have been received, the routine returns immediately with a count of 0x00. If a packet is ready, the routine returns with count set to the length of the data packet and the packet contents are copied into the supplied buffer.

This routine is only available when packet framing is enabled for the channel. Packet framing is currently supported only when the channel is configured for HDLC.

Supported Hardware:

PCI-SIO4B

Prototype:

```
int GscSio4ChannelCheckForData(  
                                int boardNumber,  
                                int channel,  
                                char *buffer,  
                                int *count);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

buffer – A pointer to the start of the data buffer that will receive the data. The buffer should be long enough to hold the longest possible packet.

count – The number of bytes that were contained in the packet and transferred to *buffer*. *Count* will be 0x00 if no packets were available.

GscSio4ChannelReceiveData

`GscSio4ChannelReceiveData(...)` starts the reception of data on the specified channel. The data received on the channel is transferred into the memory buffer pointed to by *buffer*. A total of *count* bytes will be transferred. This function may return before the transfer completes. When this function returns, the value pointed to by *id* will contain a unique identifier that can be used to determine the progress of the transfer.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelReceiveData(  
                                int boardNumber,  
                                int channel,  
                                char *buffer,  
                                int count,  
                                int *id);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

buffer – A pointer to the start of the data buffer that will receive the data. The buffer should be at least *count* bytes long.

count – The number of bytes to transfer.

id – A pointer to the location that will hold the unique transfer identifier that is assigned to this transfer. This value can be used to determine when the transfer has completed.

GscSio4ChannelReceiveDataAndWait

GscSio4ChannelReceiveDataAndWait(...) starts the reception of data on the specified channel. The data received on the channel is transferred into the memory buffer pointed to by *buffer*. A total of *count* bytes will be transferred. This function will not return until the entire transfer has completed or the timeout period has expired. If a timeout occurs, the value in *bytesTransferred* will specify the number of bytes that were actually received. (Note that if no timeout occurs, the *bytesTransferred* value is undefined.)

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelReceiveDataAndWait(  
    int boardNumber,  
    int channel,  
    char *buffer,  
    int count,  
    int timeout,  
    int *bytesTransferred);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the *GscSio4FindBoards*(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

buffer – A pointer to the start of the data buffer that will receive the data. The buffer should be at least *count* bytes long.

count – The number of bytes to transfer.

timeout – The desired timeout period (in milliseconds) for the transfer.

bytesTransferred – If a timeout occurs, this value will specify the total number of bytes that were actually received. If no timeout occurs, this value is undefined.

GscSio4ChannelTransmitData

`GscSio4ChannelTransmitData(...)` starts the transmission of data on the specified channel. The data to be transmitted on the channel is transferred from the memory buffer pointed to by *buffer*. A total of *count* bytes will be transferred. This function may return before the transfer completes. When this function returns, the value pointed to by *id* will contain a unique identifier that can be used to determine the progress of the transfer.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelTransmitData(  
                                int boardNumber,  
                                int channel,  
                                char *buffer,  
                                int count,  
                                int *id);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

buffer – A pointer to the start of the data buffer that will be transmitted. The buffer should be at least *count* bytes long.

count – The number of bytes to transfer.

id – A pointer to the location that will hold the unique transfer identifier that is assigned to this transfer. This value can be used to determine when the transfer has completed.

GscSio4ChannelTransmitDataAndWait

`GscSio4ChannelTransmitDataAndWait(...)` starts the transmission of data on the specified channel. The data to be transmitted on the channel is transferred from the memory buffer pointed to by *buffer*. A total of *count* bytes will be transferred. This function will not return until the entire transfer has completed or the timeout period has expired. If a timeout occurs, the value in *bytesTransferred* will specify the number of bytes that were actually transmitted. (Note that if no timeout occurs, the *bytesTransferred* value is undefined.)

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelTransmitData(  
                                int boardNumber,  
                                int channel,  
                                char *buffer,  
                                int count,  
                                int timeout  
                                int *bytesTransferred);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

buffer – A pointer to the start of the data buffer that will be transmitted. The buffer should be at least *count* bytes long.

count – The number of bytes to transfer.

timeout – The desired timeout period (in milliseconds) for the transfer.

bytesTransferred – If a timeout occurs, this value will specify the total number of bytes that were actually transmitted. If no timeout occurs, this value is undefined.

GscSio4ChannelQueryTransfer

`GscSio4ChannelQueryTransfer(...)` is used to determine the status of a transfer that was initiated by a call to either `GscSio4ChannelReceiveData (...)` or `GscSio4ChannelTransmitData (...)`. The result is returned in *stat* and will be 0 if the transfer has completed or non-zero if it has not completed.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelQueryTransfer(  
                                int boardNumber,  
                                int channel,  
                                int *stat,  
                                int id);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

stat – A pointer to the location that will hold the returned status of the transfer. The *stat* will be 0 if the transfer has completed. Otherwise, it will hold the number of bytes left to transfer.

id – The unique ID that was assigned to the transfer by the call to either `GscSio4ChannelReceiveData(...)` or `GscSio4ChannelTransmitData(...)`

GscSio4ChannelWaitForTransfer

GscSio4ChannelWaitForTransfer (...) is used to wait for the completion of a transfer that was initiated by a call to either *GscSio4ChannelReceiveData* (...) or *GscSio4ChannelTransmitData* (...). The routine will return when either the transfer completes or the timeout period expires. If the timeout period expires, the *bytesTransferred* parameter will be updated with the number of bytes that were successfully transferred. If the transfer completes, or another type of error occurs, the *bytesTransferred* parameter will be -1.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelWaitForTransfer(  
                                int boardNumber,  
                                int channel,  
                                int timeout,  
                                int id,  
                                int *bytesTransferred);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the *GscSio4FindBoards*(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

timeout – The desired timeout value in milliseconds that the routine will wait for the transfer to complete.

id – The unique ID that was assigned to the transfer by the call to either *GscSio4ChannelReceiveData*(...) or *GscSio4ChannelTransmitData*(...)

bytesTransferred - A pointer to the location that will hold the number of bytes that were actually transferred if the timeout period expires. This value will be -1 if the transfer completes, or an error occurs.

GscSio4ChannelFlushTransfer

GscSio4ChannelFlushTransfer (...) is used to force any data that is in the Rx FIFO to be transferred via DMA to memory. For a Tx channel, data is transferred to the Tx FIFO until it is full. Calling this routine is only necessary when a transfer did not complete on its own, or when aborting a transfer that has not completed.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelFlushTransfer(  
                                int boardNumber,  
                                int channel,  
                                int id);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

id – The unique ID that was assigned to the transfer by the call to either GscSio4ChannelReceiveData(...) or GscSio4ChannelTransmitData(...)

GscSio4ChannelRemoveTransfer

GscSio4ChannelRemoveTransfer (...) is used to remove a pending transfer from the transfer queue. Calling this routine is only necessary when a transfer did not complete on its own, or to abort a transfer that has not completed. If a transfer ID of -1 is passed to the routine, all pending transfers will be removed.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelRemoveTransfer(  
                                int boardNumber,  
                                int channel,  
                                int id,  
                                int *bytesTransferred);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

id – The unique ID that was assigned to the transfer by the call to either GscSio4ChannelReceiveData(...) or GscSio4ChannelTransmitData(...)

bytesTransferred - A pointer to the location that will hold the number of bytes that were actually transferred before the call to GscSio4ChannelRemoveTransfer (). This value will be -1 if the transfer had already completed, or an error occurs.

GscSio4ChannelRegisterInterrupt

Due to differences in the handling of hardware interrupt generation/notification and callbacks between 'C' and LabView, the function GscSio4ChannelRegisterInterrupt() is not supported under LabView.

Supported Hardware:

N/A

Prototype:

N/A

Parameters:

N/A

GscSio4ChannelSetClock

`GscSio4ChannelSetClock(...)` is used to set the serial bit rate (baud rate) for a specific channel. Under normal conditions, this routine will not be used since the `GscSio4ChannelSetMode(...)` function sets the channels bit rate when the channel's mode is set. This function is provided to allow the bit rate to be changed without re-configuring the channel.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelSetClock(  
                                int boardNumber,  
                                int channel,  
                                int frequency);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

frequency – The desired bit rate for this channel. This value is specified in Hz and can range from 100 to 10000000 (1000000 for async channels).

GscSio4ChannelSetClockSource

`GscSio4ChannelSetClockSource(...)` is used to set the clock source for the Transmitter and Receiver of a channel.

Supported Hardware:

All

Prototype:

```
int GscSio4ChannelSetClock(  
                                int boardNumber,  
                                int channel,  
                                int txSource,  
                                int rxSource);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

txSource – The desired clock source for the Transmitter. The valid values are defined below.

rxSource – The desired clock source for the Receiver. The valid values are defined below.

`GSC_CLOCK_INTERNAL` – The clock is driven by the on board programmable oscillator. The bit rate is set by either the `GscSio4ChannelSetMode()` or the `GscSio4ChannelSetClock()` functions.

`GSC_CLOCK_EXTERNAL` – The clock is driven by the `RxCk` pin of the cable. The bit rate is determined by the external clock, but should also be set by either the `GscSio4ChannelSetMode()` or the `GscSio4ChannelSetClock()` functions to ensure optimal performance.

Protocol Level Routines

The Protocol Level Routines perform functions that apply to a specific protocol on a single channel on an SIO4 board. Each of these routines requires the board number (*boardNumber*) as the first parameter and the channel number (*channel*) as the second parameter. The board number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system. The channel number will always be 1, 2, 3, or 4.

These routines can be called at any time. All of these functions return zero if successful or a non-zero error code if a failure occurs.

GscSio4ChannelSetHdlcCrcMode / GscSio4ChannelGetHdlcCrcMode

`GscSio4ChannelSetHdlcCrcMode(...)` sets the mode for CRC generation/detection for a single channel of the SIO4 board. The CRC mode can be set to None, 16 bit, 32 bit, or CCITT. This routine is also used to set the initial value of the CRC register. This value can be set to either all 0 or all 1.

Supported Hardware:

PCI-SIO4B

Prototype:

```
int GscSio4ChannelSetHdlcCrcMode(  
                                int boardNumber,  
                                int channel,  
                                int crcMode,  
                                int initialValue);  
  
int GscSio4ChannelGetHdlcCrcMode(  
                                int boardNumber,  
                                int channel,  
                                int *crcMode,  
                                int *initialValue);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the `GscSio4FindBoards(...)` function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

crcMode – The desired/current CRC type for this channel. The value should be one of the following:

GSC_CRC_NONE – Sets the channel to use no CRC.

GSC_CRC_16 – Sets the channel to use a 16 bit CRC.

GSC_CRC_32 – Sets the channel to use a 32 bit CRC.

GSC_CRC_CCITT - Sets the channel to use a CCITT CRC.

initialValue – The desired/current initial value for the CRC register. The value should be one of the following:

GSC_CRC_INIT_0 – Initializes the CRC register to all 0's.

GSC_CRC_INIT_1 – Initializes the CRC register to all 1's.

GscSio4ChannelSetBiSyncPattern / GscSio4ChannelGetBiSyncPattern

GscSio4ChannelSetBiSyncPattern(...) sets the two bytes that are used for the Sync Pattern when the channel is configured for BiSync mode.

Supported Hardware:

PCI-SIO4B

Prototype:

```
int GscSio4ChannelSetBiSyncPattern(  
                                int boardNumber,  
                                int channel,  
                                int txSync,  
                                int rxSync);
```

```
int GscSio4ChannelGetBiSyncPattern(  
                                int boardNumber,  
                                int channel,  
                                int *txSync,  
                                int *rxSync);
```

Parameters:

boardNumber – The number of the desired board. This number corresponds to the results of the GscSio4FindBoards(...) function. Note that this number will always be 1 in a single board system.

channel – The desired channel number. This number will be 1, 2, 3, or 4.

txSync – The desired/current value for the sync pattern for the transmitter.

rxSync – The desired/current value for the sync pattern for the receiver.

Structures and Macro Definitions

This section contains the descriptions of the various structures and macro definitions available to users of the API.

Devices Structure

Interrupt Callback Prototype

Channel Mode Definitions

The Channel Mode Definitions are used to set the current operating protocol for each channel of the SIO4 board. These definitions are passed as a parameter of the GscSio4ChannelSetMode(...) command.

Macro	Protocol	Defaults
GSC_MODE_ASYNC	Asynchronous Mode	8 Data Bits No Parity 1 Stop Bit 16x Clock NRZ Encoding
GSC_MODE_HDLC	HDLC/SDLC Mode	8 Data Bits NRZ Encoding
GSC_MODE_SYNC	Synchronous Mode*	8 Data Bits 0 Gap Bits NRZ Encoding
GSC_MODE_SYNC_ENV	Synchronous Mode w/ Envelope*	8 Data Bits 0 Gap Bits NRZ Encoding
GSC_MODE_ISO	Isochronous Mode	8 Data Bits NRZ Encoding
GSC_MODE_MONOSYNC	Monosync Mode	8 Data Bits NRZ Encoding
GSC_MODE_BISYNC	BiSync Mode	8 Data Bits NRZ Encoding
GSC_MODE_TRANS_BISYNC	Transparent BiSync Mode	8 Data Bits NRZ Encoding
GSC_MODE_802_3	IEEE 802.3 Ethernet Mode	8 Data Bits NRZ Encoding

* These are the only modes that are available on the –SYNC card. They are not available on the standard card.

Channel Encoding Definitions

The Channel Encoding Definitions are used to set the desired channel encoding for each channel of the SIO4 board. These definitions are passed as a parameter of the GscSio4ChannelSetEncoding(...) command.

Macro	Description
GSC_ENCODING_NRZ	
GSC_ENCODING_NRZB	
GSC_ENCODING_NRZI_MARK	
GSC_ENCODING_NRZI_SPACE	
GSC_ENCODING_BIPHASE_MARK	
GSC_ENCODING_BIPHASE_SPACE	
GSC_ENCODING_BIPHASE_LEVEL	
GSC_ENCODING_DIFF_BIPHASE_LEVEL	

Channel Protocol and Termination Definitions

GSC_PROTOCOL_RS422_RS485,
GSC_PROTOCOL_RS423,
GSC_PROTOCOL_RS232,
GSC_PROTOCOL_RS530_1,
GSC_PROTOCOL_RS530_2,
GSC_PROTOCOL_V35_1,
GSC_PROTOCOL_V35_2,
GSC_PROTOCOL_RS422_RS423_1,
GSC_PROTOCOL_RS422_RS423_2,

GSC_TERMINATION_ENABLED,
GSC_TERMINATION_DISABLED,

Channel Interrupt Definitions

```
GSC_INTR_RISING_EDGE,  
GSC_INTR_FALLING_EDGE,  
GSC_INTR_HIGH_TRUE,  
GSC_INTR_LOW_TRUE,  
  
GSC_INTR_SYNC_DETECT           = 0x0001,  
GSC_INTR_USC                   = 0x0002,  
GSC_INTR_TX_FIFO_EMPTY        = 0x0004,  
GSC_INTR_TX_FIFO_FULL         = 0x0008,  
GSC_INTR_TX_FIFO_ALMOST_EMPTY = 0x0010,  
GSC_INTR_RX_FIFO_EMPTY        = 0x0020,  
GSC_INTR_RX_FIFO_FULL         = 0x0040,  
GSC_INTR_RX_FIFO_ALMOST_FULL  = 0x0080,  
GSC_INTR_TX_TRANSFER_COMPLETE = 0x0100,  
GSC_INTR_RX_TRANSFER_COMPLETE = 0x0200,  
GSC_INTR_RX_ENVELOPE          = GSC_INTR_SYNC_DETECT,  
// -Sync card definition
```


Channel Pin Definitions

```
GSC_PIN_DTE,  
GSC_PIN_DCE,  
GSC_PIN_AUTO,  
GSC_PIN_GPIO,  
GSC_PIN_RX_CLOCK, // Keep these enums in order  
GSC_PIN_RX_DATA,  //  
GSC_PIN_CTS,       //  
GSC_PIN_DCD,       //  
GSC_PIN_TX_CLOCK,  //  
GSC_PIN_TX_DATA,   //  
GSC_PIN_RTS,       //  
GSC_PIN_AUXCLK,    // Keep these enums in order  
GSC_PIN_RX_ENV,  
GSC_PIN_TX_ENV,
```

Channel Parity Definitions

GSC_PARITY_NONE,
GSC_PARITY_EVEN,
GSC_PARITY_ODD,
GSC_PARITY_MARK,
GSC_PARITY_SPACE,

Channel Async Stop Bits Definition

GSC_STOP_BITS_0,
GSC_STOP_BITS_1,
GSC_STOP_BITS_1_5,
GSC_STOP_BITS_2,

Loopback Definitions

GSC_LOOP_NONE,
GSC_LOOP_INTERNAL,
GSC_LOOP_EXTERNAL,

HDLC CRC Definitions

GSC_CRC_NONE,
GSC_CRC_16,
GSC_CRC_32,
GSC_CRC_CCITT,
GSC_CRC_INIT_0,
GSC_CRC_INIT_1,

Local Register Definitions

The Local Register Definitions are used to access the various registers that are contained in the on board FPGA. These registers should not be accessed during normal operation and are included only for diagnostic purposes. For detailed descriptions of the registers, refer to the SIO4 hardware user's manual.

Macro	Value	Description
FW_REVISION_REG	0x0000	Firmware Revision Register
BOARD_CONTROL_REG	0x0004	Board Control Register
BOARD_STATUS_REG	0x0008	Board Status Register
CLOCK_CONTROL_REG	0x000c	Clock Control Register
TX_ALMOST_BASE_REG	0x0010	Base value for the Tx Almost registers
RX_ALMOST_BASE_REG	0x0014	Base value for the Rx Almost registers
DATA_FIFO_BASE_REG	0x0018	Base value for the Tx and Rx Data FIFOs
CONTROL_STATUS_BASE_REG	0x001c	Base value for the Control/Status registers
SYNC_CHARACTER_BASE_REG	0x0050	Base value for the Sync Byte Registers
INTERRUPT_CONTROL_REG	0x0060	Interrupt Control Register
INTERRUPT_STATUS_REG	0x0064	Interrupt Status/Clear Register
INTERRUPT_EDGE_LEVEL_REG	0x0068	Interrupt Edge/Level Register (RO)
INTERRUPT_HI_LO_REG	0x006c	Interrupt High/Low, Rising/Falling register
PIN_SOURCE_BASE_REG	0x0080	Base value for the Pin Source Registers
PIN_STATUS_BASE_REG	0x0090	Base value for the Pin Status Registers
POSC_RAM_ADDRESS_REG	0x00a0	Programmable OSC Address Register
POSC_RAM_DATA_REG	0x00a4	Programmable OSC Data Register
POSC_CONTROL_STATUS_REG	0x00a8	Programmable OSC Control/Status Register
TX_COUNT_BASE_REG	0x00b0	
FIFO_COUNT_BASE_REG	0x00d0	Base value for the FIFO Count Registers
FIFO_SIZE_BASE_REG	0x00e0	Base value for the FIFO Size Registers
FEATURES_REG	0x00fc	Features Register

Channel Register Definitions

The Channel Register Definitions are used to access the various registers that are contained in the Zilog USC chip for each channel. These registers should not be accessed during normal operation and are included only for diagnostic purposes. For detailed descriptions of the registers, refer to the Zilog USC hardware user's manual. These registers do not exist on –SYNC versions of the SIO4B/BX.

Macro	Value	Description
USC_CCAR	0x0000	Channel Command/Address Register
USC_CMR	0x0002	Channel Mode Register
USC_CCSR	0x0004	Channel Command/Status Register
USC_CCR	0x0006	Channel Control Register
USC_TMDR	0x000c	Test Mode Data Register
USC_TMCR	0x000e	Test Mode Control Register
USC_CMCR	0x0010	Clock Mode Control Register
USC_HCR	0x0012	Hardware Configuration Register
USC_IVR	0x0014	Interrupt Vector Register
USC_IOCRR	0x0016	I/O Control Register
USC_ICR	0x0018	Interrupt Control Register
USC_DCCR	0x001a	Daisy Chain Control Register
USC_MISR	0x001c	Misc. Interrupt Status Register
USC_SICR	0x001e	Status Interrupt Control Register
USC_RDR	0x0020	Receive Data Register (RO)
USC_RMR	0x0022	Receive Mode Register
USC_RCSR	0x0024	Receive Command Status Register
USC_RICR	0x0026	Receive Interrupt Control Register
USC_RSR	0x0028	Receive Sync Register
USC_RCLR	0x002a	Receive Count Limit Register
USC_RCCR	0x002c	Receive Character Count Register
USC_TC0R	0x002e	Time Constant 0 Register
USC_TDR	0x0030	Transmit Data Register (WO)
USC_TMR	0x0032	Transmit Mode Register
USC_TCSR	0x0034	Transmit Command Status Register
USC_TICR	0x0036	Transmit Interrupt Control Register
USC_TSR	0x0038	Transmit Sync Register
USC_TCLR	0x003a	Transmit Count Limit Register
USC_TCCR	0x003c	Transmit Character Count Register
USC_TC1R	0x003e	Time Constant 1 Register

Miscellaneous Token Definitions

GSC_ENABLED,
GSC_DISABLED,

GSC_CLOCK_INTERNAL,
GSC_CLOCK_EXTERNAL,

GSC_LSB_FIRST,
GSC_MSB_FIRST,