

18AISS8A08

**16-bit, 4 A/D channels, 4 D/A Channels, 1M S/S/Ch
16-bit Digital I/O**

PCI66-18AISS8A08

Linux Device Driver And API Library User Manual

**Manual Revision: April 21, 2023
Driver Release Version 1.4.102.45.1**

**General Standards Corporation
8302A Whitesburg Drive
Huntsville, AL 35802
Phone: (256) 880-8787
Fax: (256) 880-8788**

URL: <http://www.generalstandards.com>

E-mail: sales@generalstandards.com

E-mail: support@generalstandards.com

Preface

Copyright © 2019-2023, **General Standards Corporation**

Additional copies of this manual or other literature may be obtained from:

General Standards Corporation
8302A Whitesburg Dr.
Huntsville, Alabama 35802
Phone: (256) 880-8787
FAX: (256) 880-8788
URL: <http://www.generalstandards.com>
E-mail: sales@generalstandards.com

General Standards Corporation makes no warranty of any kind with regard to this documentation and/or software, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Although extensive editing and reviews are performed before release, **General Standards Corporation** assumes no responsibility for any errors, inaccuracies or omissions herein. This documentation, information and software are made available solely on an “as-is” basis. Nor is there any commitment to update or keep current this documentation.

General Standards Corporation does not assume any liability arising out of the application or use of documentation, software, product or circuit described herein, nor is any license conveyed under any patent rights or any rights of others.

General Standards Corporation assumes no responsibility for any consequences resulting from omissions or errors in this manual or from the use of information contained herein.

General Standards Corporation reserves the right to make any changes, without notice, to this documentation, software or product, to improve accuracy, clarity, reliability, performance, function, or design.

ALL RIGHTS RESERVED.

GSC is a trademark of **General Standards Corporation**.

PLX and PLX Technology are trademarks of PLX Technology, Inc.

Table of Contents

1. Introduction.....	8
1.1. Purpose.....	8
1.2. Acronyms.....	8
1.3. Definitions	8
1.4. Software Overview	8
1.4.1. Basic Software Architecture	8
1.4.2. API Library.....	9
1.4.3. Device Driver	9
1.5. Hardware Overview	9
1.6. Reference Material.....	9
1.7. Licensing.....	10
2. Installation.....	11
2.1. CPU and Kernel Support.....	11
2.1.1. 32-bit Support Under 64-bit Environments	12
2.2. The /proc/ File System	12
2.3. File List.....	12
2.4. Directory Structure.....	12
2.5. Installation	13
2.6. Removal.....	13
2.7. Overall Make Script.....	13
2.8. Environment Variables	14
2.8.1. GSC_API_COMP_FLAGS.....	14
2.8.2. GSC_API_LINK_FLAGS.....	14
2.8.3. GSC_LIB_COMP_FLAGS.....	14
2.8.4. GSC_LIB_LINK_FLAGS.....	15
2.8.5. GSC_APP_COMP_FLAGS.....	15
2.8.6. GSC_APP_LINK_FLAGS.....	15
3. Main Interface Files.....	16
3.1. Main Header File	16
3.2. Main Library File.....	16
3.2.1. Build	16
3.2.2. System Libraries.....	17
4. API Library	18
4.1. Files.....	18
4.2. Build	18
4.3. Library Use	18
4.4. Macros	19
4.4.1. IOCTL Services.....	19

4.4.2. Registers	19
4.5. Data Types	20
4.6. Functions.....	20
4.6.1. aiss8ao8_close()	20
4.6.2. aiss8ao8_init()	20
4.6.3. aiss8ao8_ioctl().....	21
4.6.4. aiss8ao8_open().....	22
4.6.5. aiss8ao8_read().....	23
4.6.6. aiss8ao8_write()	24
4.7. IOCTL Services	25
4.7.1. AISS8AO8_IOCTL_AI_BUF_CLEAR	25
4.7.2. AISS8AO8_IOCTL_AI_BUF_LEVEL.....	25
4.7.3. AISS8AO8_IOCTL_AI_BUF_OVERFLOW	25
4.7.4. AISS8AO8_IOCTL_AI_BUF_THR_LVL	26
4.7.5. AISS8AO8_IOCTL_AI_BUF_THR_STS	26
4.7.6. AISS8AO8_IOCTL_AI_BUF_UNDERFLOW	26
4.7.7. AISS8AO8_IOCTL_AI_BURST_ENABLE	27
4.7.8. AISS8AO8_IOCTL_AI_BURST_SIZE.....	27
4.7.9. AISS8AO8_IOCTL_AI_BURST_STATUS	27
4.7.10. AISS8AO8_IOCTL_AI_CHAN_SEL.....	28
4.7.11. AISS8AO8_IOCTL_AI_CLK_TRIG_OUT	28
4.7.12. AISS8AO8_IOCTL_AI_CLOCK_SRC	28
4.7.13. AISS8AO8_IOCTL_AI_ENABLE	29
4.7.14. AISS8AO8_IOCTL_AI_GRP_A_FILTER.....	29
4.7.15. AISS8AO8_IOCTL_AI_GRP_B_FILTER	29
4.7.16. AISS8AO8_IOCTL_AI_I_LOOP_TERM	30
4.7.17. AISS8AO8_IOCTL_AI_MODE	30
4.7.18. AISS8AO8_IOCTL_AI_RANGE	30
4.7.19. AISS8AO8_IOCTL_AI_SW_CLOCK	31
4.7.20. AISS8AO8_IOCTL_AI_SW_TRIGGER.....	31
4.7.21. AISS8AO8_IOCTL_AI_TRIG_SRC	31
4.7.22. AISS8AO8_IOCTL_AO_BUF_CLEAR.....	32
4.7.23. AISS8AO8_IOCTL_AO_BUF_EMPTY	32
4.7.24. AISS8AO8_IOCTL_AO_BUF_FULL.....	32
4.7.25. AISS8AO8_IOCTL_AO_BUF_LEVEL	32
4.7.26. AISS8AO8_IOCTL_AO_BUF_LOAD_REQ.....	33
4.7.27. AISS8AO8_IOCTL_AO_BUF_LOAD_STS	33
4.7.28. AISS8AO8_IOCTL_AO_BUF_MODE.....	33
4.7.29. AISS8AO8_IOCTL_AO_BUF_OVER_DATA.....	33
4.7.30. AISS8AO8_IOCTL_AO_BUF_OVER_FRAM.....	34
4.7.31. AISS8AO8_IOCTL_AO_BUF_THR_LVL	34
4.7.32. AISS8AO8_IOCTL_AO_BUF_THR_STS.....	35
4.7.33. AISS8AO8_IOCTL_AO_BURST_ENABLE	35
4.7.34. AISS8AO8_IOCTL_AO_BURST_STATUS	35
4.7.35. AISS8AO8_IOCTL_AO_CHAN_SEL	36
4.7.36. AISS8AO8_IOCTL_AO_CLK_TRIG_OUT	36
4.7.37. AISS8AO8_IOCTL_AO_CLOCK_READY	36
4.7.38. AISS8AO8_IOCTL_AO_CLOCK_SRC	36
4.7.39. AISS8AO8_IOCTL_AO_ENABLE.....	37
4.7.40. AISS8AO8_IOCTL_AO_MODE.....	37
4.7.41. AISS8AO8_IOCTL_AO_OUTPUT_MODE	37
4.7.42. AISS8AO8_IOCTL_AO_RANGE.....	38
4.7.43. AISS8AO8_IOCTL_AO_SW_CLOCK.....	38
4.7.44. AISS8AO8_IOCTL_AO_SW_TRIGGER	38

4.7.45. AISS8AO8_IOCTL_AO_TRIG_SRC.....	39
4.7.46. AISS8AO8_IOCTL_AUTO_CAL_STS	39
4.7.47. AISS8AO8_IOCTL_AUTO_CALIBRATE.....	39
4.7.48. AISS8AO8_IOCTL_DATA_FORMAT	39
4.7.49. AISS8AO8_IOCTL_DIO_DIR_OUT	40
4.7.50. AISS8AO8_IOCTL_DIO_READ	40
4.7.51. AISS8AO8_IOCTL_DIO_WRITE	40
4.7.52. AISS8AO8_IOCTL_GEN_A_ENABLE	41
4.7.53. AISS8AO8_IOCTL_GEN_A_NDIV	41
4.7.54. AISS8AO8_IOCTL_GEN_B_ENABLE.....	41
4.7.55. AISS8AO8_IOCTL_GEN_B_NDIV	42
4.7.56. AISS8AO8_IOCTL_GEN_C_ENABLE.....	42
4.7.57. AISS8AO8_IOCTL_GEN_C_NDIV	42
4.7.58. AISS8AO8_IOCTL_GEN_D_ENABLE	42
4.7.59. AISS8AO8_IOCTL_GEN_D_NDIV	43
4.7.60. AISS8AO8_IOCTL_INITIALIZE	43
4.7.61. AISS8AO8_IOCTL_IRQ_ENABLE	43
4.7.62. AISS8AO8_IOCTL_QUERY	44
4.7.63. AISS8AO8_IOCTL_REG_MOD.....	45
4.7.64. AISS8AO8_IOCTL_REG_READ	46
4.7.65. AISS8AO8_IOCTL_REG_WRITE	46
4.7.66. AISS8AO8_IOCTL_RX_IO_ABORT.....	47
4.7.67. AISS8AO8_IOCTL_RX_IO_MODE.....	47
4.7.68. AISS8AO8_IOCTL_RX_IO_OVERFLOW	47
4.7.69. AISS8AO8_IOCTL_RX_IO_TIMEOUT	48
4.7.70. AISS8AO8_IOCTL_RX_IO_UNDERFLOW	48
4.7.71. AISS8AO8_IOCTL_TX_IO_ABORT	49
4.7.72. AISS8AO8_IOCTL_TX_IO_MODE.....	49
4.7.73. AISS8AO8_IOCTL_TX_IO_OVERFLOW	49
4.7.74. AISS8AO8_IOCTL_TX_IO_TIMEOUT.....	50
4.7.75. AISS8AO8_IOCTL_WAIT_CANCEL.....	50
4.7.76. AISS8AO8_IOCTL_WAIT_EVENT.....	51
4.7.77. AISS8AO8_IOCTL_WAIT_STATUS.....	53
4.7.78. AISS8AO8_IOCTL_WARP_MODE	54

5. The Driver..... 55

5.1. Files.....	55
5.2. Build	55
5.3. Startup.....	55
5.3.1. Manual Driver Startup Procedures	55
5.3.2. Automatic Driver Startup Procedures.....	56
5.4. Verification	57
5.5. Version.....	58
5.6. Shutdown	58

6. Document Source Code Examples..... 59

6.1. Files.....	59
6.2. Build	59
6.3. Library Use	59

7. Utility Source Code	60
7.1. Files.....	60
7.2. Build	60
7.3. Library Use	60
8. Operating Information	61
8.1. Debugging Aids	61
8.1.1. Device Identification	61
8.1.2. Detailed Register Dump	61
8.2. Analog Input Configuration	61
8.3. Analog Output Configuration	61
8.4. I/O Modes	62
8.4.1. PIO - Programmed I/O	62
8.4.2. BMDMA - Block Mode DMA	62
8.4.3. DMDMA - Demand Mode DMA	62
9. Sample Applications	63
9.1. aout - Analog Output - ../aout/	63
9.2. din - Digital Input - ../din/	63
9.3. dout - Digital Output - ../dout/	63
9.4. fsamp - Sample Rate - ../fsamp/	63
9.5. id - Identify Board - ../id/	63
9.6. regs - Register Access - ../regs/	63
9.7. rxrate - Receive Rate - ../rxrate/	63
9.8. savedata - Save Acquired Data - ../savedata/	63
9.9. signals - Digital Signals - ../signals/	63
9.10. txrate - Transmit Rate - ../txrate/	64
Document History	65

Table of Figures

Figure 1 Basic architectural representation.....9

1. Introduction

1.1. Purpose

The purpose of this document is to describe the interface to the 18AISS8AO8 API Library and to the underlying Linux device driver. The API Library software provides the interface between "Application Software" and the device driver. The driver software provides the interface between the API Library and the actual 18AISS8AO8 hardware. The API Library and driver interfaces are based on the board's functionality.

1.2. Acronyms

The following is a list of commonly occurring acronyms which may appear throughout this document.

Acronyms	Description
API	Application Programming Interface
BMDMA	Block Mode DMA
DMA	Direct Memory Access
DMDMA	Demand Mode DMA
GSC	General Standards Corporation
PCI	Peripheral Component Interconnect
PCI66	This refers to a PCI device capable of operating at 66MHz bus speeds.
PIO	Programmed I/O
RGA	Rate Generator A
RGB	Rate Generator B
RGC	Rate Generator C
RGD	Rate Generator D

1.3. Definitions

The following is a list of commonly occurring terms which may appear throughout this document.

Term	Definition
...	This is a shortcut representation of the 18AISS8AO8 installation directory or any of its subdirectories.
18AISS8AO8	This is used as a general reference to any board supported by this driver.
API Library	This is a library that provides application-level access to 18AISS8AO8 hardware.
Application	This is a user mode process, which runs in user space with user mode privileges.
Driver	This is the 18AISS8AO8 device driver, which runs in kernel space with kernel mode privileges.
Library	This is usually a general reference to the API Library.

1.4. Software Overview

1.4.1. Basic Software Architecture

This section describes the general architecture for the basic components that comprise 18AISS8AO8 applications. The overall architecture is illustrated in Figure 1 below.




Figure 1 Basic architectural representation.

1.4.2. API Library

The primary means of accessing 18AISS8AO8 boards is via the 18AISS8AO8 API Library. This library forms a thin layer between the application and the driver. Additional information is given in section 4 beginning on page 18. With the library, applications are able to open and close a device and, while open, perform I/O control and read and write operations.

1.4.3. Device Driver

The device driver is the host software that provides a means of communicating directly with 18AISS8AO8 hardware. The driver executes under control of the operating system and runs in Kernel Mode as a Kernel Mode device driver. The driver is implemented as a standard dynamically loadable Linux device driver written in the C programming language. While applications can access the driver directly without use of the API Library, it is recommended that all access is made through the library.

1.5. Hardware Overview

The 18AISS8AO8 is a high-performance, 16-bit analog I/O board that incorporates up to four input channels and up to four output channels. The host side connection is PCI based and the form factor is according to the model ordered. The board is capable of acquiring and generating data at up to 1M samples per second over each channel. Internal clocking permits sampling rates from 1M samples per second down to near zero samples per second. Onboard storage permits data buffering of up to 256K input samples, for all input channels collectively, and up to 256K output samples, for all output channels collectively, between the cable interface and the PCI bus. This allows the 18AISS8AO8 to sustain continuous throughput over the cable interface independent of the PCI bus interface. The 18AISS8AO8 also permits multiple boards to be synchronized so that all boards sample data in unison. In addition, the board includes auto-calibration capability, as well as 16 digital I/O signals configurable per byte as input or output.

1.6. Reference Material

The following reference material may be of particular benefit in using the 18AISS8AO8. The specifications provide the information necessary for an in depth understanding of the specialized features implemented on this board.

- The applicable *18AISS8AO8 User Manual* from General Standards Corporation.

- The *PCI9056 PCI Bus Master Interface Chip* data handbook from PLX Technology, Inc.

PLX Technology Inc.
870 Maude Avenue
Sunnyvale, California 94085 USA
Phone: 1-800-759-3735
WEB: <http://www.plxtech.com>

1.7. Licensing

For licensing information please refer to the text file `LICENSE.txt` in the root installation directory.

2. Installation

2.1. CPU and Kernel Support

The driver is designed to operate with Linux kernel versions 6.x, 5.x, 4.x, 3.x, 2.6, 2.4 and 2.2 running on a PC system with one or more x86 processors. This release of the driver supports the below listed kernels.

Kernel	Distribution
6.0.7	Red Hat Fedora Core 37
5.17.5	Red Hat Fedora Core 36
5.14.10	Red Hat Fedora Core 35
5.11.12	Red Hat Fedora Core 34
5.8.15	Red Hat Fedora Core 33
5.6.6	Red Hat Fedora Core 32
5.3.7	Red Hat Fedora Core 31
5.0.9	Red Hat Fedora Core 30
4.18.16	Red Hat Fedora Core 29
4.16.3	Red Hat Fedora Core 28
4.13.9	Red Hat Fedora Core 27
4.11.8	Red Hat Fedora Core 26
4.8.6	Red Hat Fedora Core 25
4.5.5	Red Hat Fedora Core 24
4.2.3	Red Hat Fedora Core 23
4.0.4	Red Hat Fedora Core 22
3.17.4	Red Hat Fedora Core 21
3.11.10	Red Hat Fedora Core 20
3.9.5	Red Hat Fedora Core 19
3.6.10	Red Hat Fedora Core 18
3.3.4	Red Hat Fedora Core 17
3.1.0	Red Hat Fedora Core 16
2.6.38	Red Hat Fedora Core 15
2.6.35	Red Hat Fedora Core 14
2.6.33	Red Hat Fedora Core 13
2.6.31	Red Hat Fedora Core 12
2.6.29	Red Hat Fedora Core 11
2.6.27	Red Hat Fedora Core 10
2.6.25	Red Hat Fedora Core 9
2.6.23	Red Hat Fedora Core 8
2.6.21	Red Hat Fedora Core 7
2.6.18	Red Hat Fedora Core 6
2.6.15	Red Hat Fedora Core 5
2.6.11	Red Hat Fedora Core 4
2.6.9	Red Hat Fedora Core 3

NOTE: Some older kernel versions are supported (the sources are maintained), but are not tested.

NOTE: While only Red Hat Fedora distributions are listed, numerous other distributions are supported and have been tested on an as needed basis.

NOTE: The driver will have to be built before being used as it is provided in source form only.

NOTE: The driver has not been tested with a non-versioned kernel.

NOTE: The driver is designed for SMP support, but has not undergone SMP specific testing.

2.1.1. 32-bit Support Under 64-bit Environments

This driver supports 32-bit applications under 64-bit environments. The availability of this feature in the kernel depends on a 64-bit kernel being configured to support 32-bit application compatibility. Additionally, 2.6 kernels prior to 2.6.11 implemented 32-bit compatibility in a way that resulted in some drivers not being able to take advantage of the feature. (In these kernels a driver's IOCTL command codes must be globally unique. Beginning with 2.6.11 this requirement has been lifted.) If the driver is not able to provide 32-bit support under a 64-bit kernel, the "32-bit support" field in the `/proc/18aiss8ao8` file will be "no".

2.2. The `/proc/` File System

While the driver is running, the text file `/proc/18aiss8ao8` can be read to obtain information about the driver. Each file entry includes an entry name followed immediately by a colon, a space character, and the entry value. Below is an example of what appears in the file, followed by descriptions of each entry.

```
version: 1.4.102.45
32-bit support: yes
boards: 1
models: 18AISS8AO8
```

Entry	Description
version	This gives the driver version number in the form <code>x.x.x.x</code> .
32-bit support	This reports the driver's support for 32-bit applications. This will be either "yes" or "no" for 64-bit driver builds and "yes (native)" for 32-bit builds.
boards	This identifies the total number of boards the driver detected.
models	This gives a comma separated list of the board models identified by the driver. One model will be listed for each board identified in the system. For this driver the only model numbers listed will be "18AISS8AO8."

2.3. File List

This release consists of the below listed primary files. The archive content is described in following subsections.

File	Description
<code>18aiss8ao8.linux.tar.gz</code>	This archive contains the driver, the API Library and all related files.
<code>18aiss8ao8_linux_um.pdf</code>	This is a PDF version of this user manual, which is included in the archive.

2.4. Directory Structure

The following table describes the directory structure utilized by the installed files. During installation the directory structure is created and populated with the respective files.

Directory	Content
<code>18aiss8ao8/</code>	This is the driver root directory. It contains the documentation, the Overall Make Script (section 2.7, page 13) and the below listed subdirectories.
<code>.../api/</code>	This directory contains the 18AISS8AO8 API Library (section 4, page 18).
<code>.../docsrc/</code>	This directory contains the code samples from this document (section 6 on page 59).
<code>.../driver/</code>	This directory contains the driver and its sources (section 5, page 55).
<code>.../include/</code>	This directory contains the include files for the various libraries.

.../lib/	This directory contains all of the libraries built from the driver archive.
.../samples/	This directory contains the sample applications (section 9, page 63).
.../utils/	This directory contains utility sources used by the sample applications (section 7, page 60).

2.5. Installation

Perform installation following the below listed steps. This installs the device driver, the API Library and all related sources and documentation.

1. Create and change to the directory where the files are to be installed, such as `/usr/src/linux/drivers/`. (The path name may vary among distributions and kernel versions.)
2. Copy the archive file `18aiss8ao8.linux.tar.gz` into the current directory.
3. Issue the following command to decompress and extract the files from the provided archive. This creates the directory `18aiss8ao8` in the current directory, and then copies all of the archive's files into this new directory.

```
tar -xzvf 18aiss8ao8.linux.tar.gz
```

2.6. Removal

Perform removal following the below listed steps. This removes the device driver, the API Library and all related sources and documentation.

NOTE: The following steps may require elevated privileges.

1. Shutdown the driver as described in section 5.6 on page 58.
2. Change to the directory where the driver archive was installed, which may have been `/usr/src/linux/drivers/`. (The path name may vary among distributions and kernel versions.)
3. Issue the below command to remove the driver archive and all of the installed driver files.

```
rm -rf 18aiss8ao8.linux.tar.gz 18aiss8ao8
```

4. Issue the below command to remove all of the installed device nodes.

```
rm -f /dev/18aiss8ao8.*
```

5. If the automated startup procedure was adopted (section 5.3.2, page 55), then edit the system startup script `rc.local` and remove the line that invokes the 18AISS8AO8's start script. The file `rc.local` should be located in the `/etc/rc.d/` directory.

2.7. Overall Make Script

An Overall Make Script is included in the root installation directory. Executing this script will perform a make for all build targets included in the release. The script also loads the driver and copies the API Library to `/usr/lib/`. The script is named `make_all`. Follow the below steps to perform an overall make and to load the driver.

NOTE: The following steps may require elevated privileges.

1. Change to the driver root directory (`.../18aiss8ao8/`).

- Issue the following command to remove all archive build targets.

```
./make_all clean
```

- Issue the following command to make all archive targets and to load the driver.

```
./make_all
```

NOTE: After the device driver is built the script starts the driver. After building the API Library it is copied by the script to `/usr/lib/`. The script can also perform a clean operation by adding the term “clean” as a command line argument. A clean operation does not unload the driver. However, a clean does delete the API Library file copied to `/usr/lib/`.

2.8. Environment Variables

Some build environments may require compiler or linker options not present in the provided make files. To accommodate local environment specific requirements, the provided make files incorporate support for the following set of GSC specific environment variables.

2.8.1. GSC_API_COMP_FLAGS

This environment variable accommodates adding compiler command line options when compiling source files for the API Library. The compiler used by the API Library make file is “gcc”. The content of this environment variable is noted in the make file’s output to the screen. The table below shows a portion of the screen output. The “xxx” in the table refers to the contents of the environment variable. This environment variable has no effect on compiling any other distributed source files or linking of any object files.

Undefined or Empty	== Compiling: init.c == Compiling: ioctl.c == Compiling: open.c
Defined and Not Empty	== Compiling: init.c (added 'xxx') == Compiling: ioctl.c (added 'xxx') == Compiling: open.c (added 'xxx')

2.8.2. GSC_API_LINK_FLAGS

This environment variable accommodates adding linker command line options when linking object files for the API Library. The linker used by the API Library make file is “ld”. The content of this environment variable is noted in the make file’s output to the screen. The table below shows a portion of the screen output. The “xxx” in the table refers to the contents of the environment variable. This environment variable has no effect on compiling of any source files or linking of any other object files.

Undefined or Empty	==== Linking: ../lib/lib18aiiss8ao8_api.so
Defined and Not Empty	==== Linking: ../lib/lib18aiiss8ao8_api.so (added 'xxx')

2.8.3. GSC_LIB_COMP_FLAGS

This environment variable accommodates adding compiler command line options when compiling source files for the utility libraries. The compiler used by the utility library make files is “gcc”. The content of this environment variable is noted in the make files’ output to the screen. The table below shows a portion of the screen output. The

“xxx” in the table refers to the contents of the environment variable. This environment variable has no effect on compiling any other distributed source files or linking of any object files.

Undefined or Empty	== Compiling: close.c == Compiling: init.c == Compiling: ioctl.c
Defined and Not Empty	== Compiling: close.c (added 'xxx') == Compiling: init.c (added 'xxx') == Compiling: ioctl.c (added 'xxx')

2.8.4. GSC_LIB_LINK_FLAGS

This environment variable accommodates adding linker command line options when linking object files for the utility libraries. The linker used by the utility library make files is “ld”. The content of this environment variable is noted in the make files’ output to the screen. The table below shows a portion of the screen output. The “xxx” in the table refers to the contents of the environment variable. This environment variable has no effect on compiling of any source files or linking of any other object files.

Undefined or Empty	==== Linking: ../lib/18aiss8ao8_utils.a
Defined and Not Empty	==== Linking: ../lib/18aiss8ao8_utils.a (added 'xxx')

2.8.5. GSC_APP_COMP_FLAGS

This environment variable accommodates adding compiler command line options when compiling source files for the sample applications. The compiler used by the sample application make files is “gcc”. The content of this environment variable is noted in the make files’ output to the screen. The table below shows a portion of the screen output. The “xxx” in the table refers to the contents of the environment variable. This environment variable has no effect on compiling any other distributed source files or linking of any object files.

Undefined or Empty	== Compiling: main.c == Compiling: perform.c
Defined and Not Empty	== Compiling: main.c (added 'xxx') == Compiling: perform.c (added 'xxx')

2.8.6. GSC_APP_LINK_FLAGS

This environment variable accommodates adding linker command line options when linking object files for the sample applications. The linker used by the sample application make files is “gcc”. The content of this environment variable is noted in the make files’ output to the screen. The table below shows a portion of the screen output. The “xxx” in the table refers to the contents of the environment variable. This environment variable has no effect on compiling of any source files or linking of any other object files.

Undefined or Empty	==== Linking: id
Defined and Not Empty	==== Linking: id (added 'xxx')

3. Main Interface Files

This section gives general information on the suggested device interface files to use when developing 18AISS8AO8 based applications.

3.1. Main Header File

Throughout the remainder of this document references are made to various header files included as part of the 18AISS8AO8 driver archive. For ease of use it is suggested that applications include only the single header file shown below rather than individually including those headers identified separately later in this document. Including this header file pulls in all other pertinent 18AISS8AO8 specific header files. Therefore, sources may include only this one 18AISS8AO8 header and make files may reference only this one 18AISS8AO8 include directory.

Description	File	Location
Header File	18aiiss8ao8_main.h	.../include/

3.2. Main Library File

Throughout the remainder of this document references are made to various statically linkable libraries included as part of the 18AISS8AO8 driver archive. For ease of use it is suggested that applications link only the single library file shown below rather than individually linking those libraries identified separately later in this document. Linking this library file pulls in all other pertinent 18AISS8AO8 specific static libraries. Therefore, make files may reference only this one 18AISS8AO8 static library and only this one 18AISS8AO8 library directory.

Description	File	Location
Static Library	18aiiss8ao8_main.a	.../lib/
	18aiiss8ao8_multi.a	

NOTE: For applications using the 18AISS8AO8 and no other GSC devices, link the 18aiiss8ao8_main.a library. For applications using multiple GSC device types, link the xxxx_main.a library for one of the devices and the xxxx_multi.a library for the others. Linking multiple xxxx_main.a libraries may likely produce link errors due to duplicate symbols being defined. While it may make little or no difference, it is recommended that one choose the xxxx_main.a library from the driver with the largest number in positions three (x.x.X.x.x) and/or four (x.x.x.X.x) in the driver release version number.

NOTE: The 18AISS8AO8 API Library is implemented as a shared library and is thus not linked with the 18AISS8AO8 Main Library. The API Library must be linked with applications by adding the argument `-l18aiiss8ao8_api` to the linker command line.

3.2.1. Build

The main library is built via the Overall Make Script (section 2.7, page 13). However, the main library can be rebuilt separately following the below steps.

1. Change to the directory where the main library resides (.../lib/).
2. Remove existing build targets using the below command.

```
make clean
```

3. Rebuild the main library by issuing the below command.

```
make
```

3.2.2. System Libraries

In addition to linking the static library named above, applications may need to also link in additional system libraries as noted below.

Library	gcc Link Flag
Math	-lm
POSIX Thread	-lpthread
Real Time	-lrt

4. API Library

The 18AISS8AO8 API Library is the software interface between user applications and the 18AISS8AO8 device driver. The interface is accessed by including the header file `18aiss8ao8_api.h`.

NOTE: Contact General Standards Corporation if additional library functionality is required.

4.1. Files

The library files are summarized in the table below.

File	Description
<code>api/*.c</code>	These are library source files.
<code>api/*.h</code>	These are library header files.
<code>api/makefile</code>	This is the library make file.
<code>api/makefile.dep</code>	This is an automatically generated make dependency file.
<code>include/18aiss8ao8_api.h</code>	This is the library interface header file.
<code>lib/lib18aiss8ao8_api.so</code>	This is the API Library shared library file. *

* The shared library is automatically copied to `/usr/lib/` when it is built.

4.2. Build

The API Library is built via the Overall Make Script (section 2.7, page 13), but can be built separately following the below steps.

NOTE: The API Library shared library is copied to `/usr/lib/`. Therefore, these steps may require elevated privileges.

1. Change to the directory where the library sources are installed (`.../api/`).
2. Remove existing build targets using the below command.

```
make clean
```

3. Compile the source files and build the library by issuing the below command.

```
make
```

4.3. Library Use

The library is used at application compile time, at application link time and at application run time. At compile time include the below listed header file in each source file using a component of the library interface. At link time include the below listed linker argument on the linker command line. At link time and at run time the library is found in the directory `/usr/lib/`. (The shared library file is automatically copied to `/usr/lib/` when the library is built.)

Description	File	Location	Linker Argument
Header File	<code>18aiss8ao8_api.h</code>	<code>.../include/</code>	
Shared Library	<code>lib18aiss8ao8_api.so</code>	<code>.../lib/</code>	
		<code>/usr/lib/</code>	<code>-l18aiss8ao8_api</code>

4.4. Macros

The API Library and driver interfaces include the following macros, which are defined in `18aiSS8ao8.h`.

4.4.1. IOCTL Services

The IOCTL macros are documented in section 4.7 beginning on page 25.

4.4.2. Registers

The following gives the complete set of 18AISS8AO8 registers.

4.4.2.1. GSC Registers

The following table gives the complete set of GSC specific 18AISS8AO8 registers. For detailed definitions of these registers refer to the relevant 18AISS8AO8 User Manual. Please note that the set of registers supported by any given board may vary according to model and firmware version. For the set of supported registers and detailed definitions of these registers please refer to the appropriate *18AISS8AO8 User Manual*.

Macro	Description
AISS8AO8_GSC_ACR	Assembly Configuration Register
AISS8AO8_GSC_AVR	Autocal Values Register
AISS8AO8_GSC_BCR	Board Control Register
AISS8AO8_GSC_BOOR	Buffered Output Operations Register
AISS8AO8_GSC_CLSR	Current Loop Selection Register
AISS8AO8_GSC_DIOPR	Digital I/O Port Register
AISS8AO8_GSC_IBBSR	Input Burst Block Size Register
AISS8AO8_GSC_IBDR	Input Buffer Data Register
AISS8AO8_GSC_IBSR	Input Buffer Size Register
AISS8AO8_GSC_IBTR	Input Buffer Threshold Register
AISS8AO8_GSC_ICR	Input Configuration Register
AISS8AO8_GSC_OBDR	Output Buffer Data Register
AISS8AO8_GSC_OBSR	Output Buffer Size Register
AISS8AO8_GSC_OBTR	Output Buffer Threshold Register
AISS8AO8_GSC_OCR	Output Configuration Register
AISS8AO8_GSC_PSR	Primary Status Register
AISS8AO8_GSC_RAGR	Rate-A Generator Register
AISS8AO8_GSC_RBGR	Rate-B Generator Register
AISS8AO8_GSC_RCGR	Rate-C Generator Register
AISS8AO8_GSC_RDGR	Rate-D Generator Register

4.4.2.2. PCI Configuration Registers

Access to the PCI registers is seldom required so these registers are not listed here. For the complete list of the PCI register identifiers refer to the driver header file `gsc_pci9056.h`, which is automatically included via `18aiSS8ao8.h`.

4.4.2.3. PLX PCI9056 Feature Set Registers

Access to the PLX registers is seldom required so these registers are not listed here. For the complete list of the PLX register identifiers refer to the driver header file `gsc_pci9056.h`, which is automatically included via `18aiSS8ao8.h`.

4.5. Data Types

The data types used by the API Library are described with the IOCTL services with which they are used.

4.6. Functions

The interface includes the following functions. The return values reflect the completion status of the requested operation. A value of zero indicates success. A negative value indicates that the request could not be completed successfully. The specific value returned is the negative of the corresponding error status value taken from `errno.h`. I/O services return positive values to indicate the number of bytes successfully transferred.

4.6.1. `aiss8ao8_close()`

This function is the entry point to close a connection to an open 18AISS8AO8 board. The board is put in an initialized state before this call returns.

Prototype

```
int aiss8ao8_close(int fd);
```

Argument	Description
<code>fd</code>	This is the file descriptor of the device to be closed.

Return Value	Description
0	The operation succeeded.
< 0	An error occurred. This is the negative of <code>errno</code> from <code>errno.h</code> .

Example

```
#include <stdio.h>

#include "18aiss8ao8_dsl.h"

int aiss8ao8_close_dsl(int fd)
{
    int errs;
    int ret;

    ret = aiss8ao8_close(fd);

    if (ret)
        printf("ERROR: aiss8ao8_close() returned %d\n", ret);

    errs = ret ? 1 : 0;
    return(errs);
}
```

4.6.2. `aiss8ao8_init()`

This function is the entry point to initializing the 18AISS8AO8 API Library and must be the first call into the Library. This function may be called more than once, but only the first successful call actually initializes the library. Subsequent calls perform no operation at all. All other API calls return a failure status when the API Library is not initialized.

Prototype

```
int aiss8ao8_init(void);
```

Return Value	Description
0	The operation succeeded.
< 0	An error occurred. This is the negative of <code>errno</code> from <code>errno.h</code> .

Example

```
#include <stdio.h>

#include "18aiss8ao8_dsl.h"

int aiss8ao8_init_dsl(void)
{
    int errs;
    int ret;

    ret = aiss8ao8_init();

    if (ret)
        printf("ERROR: aiss8ao8_init() returned %d\n", ret);

    errs = ret ? 1 : 0;
    return(errs);
}
```

4.6.3. aiss8ao8_ioctl()

This function is the entry point to performing setup and control operations on an 18AISS8AO8 board. This function should only be called after a successful open of the respective device. The specific operation performed varies according to the `request` argument. The `request` argument also governs the use and interpretation of the `arg` argument. The set of supported options for the `request` argument consists of the IOCTL services supported by the driver, which are defined below (section 4.7, page 25).

Prototype

```
int aiss8ao8_ioctl(int fd, int request, void* arg);
```

Argument	Description
<code>fd</code>	This is the file descriptor of the device to access.
<code>request</code>	This specifies the desired operation to be performed.
<code>arg</code>	This is a request specific argument. Refer to the IOCTL services for additional information (section 4.7, page 25).

Return Value	Description
0	The operation succeeded.
< 0	An error occurred. This is the negative of <code>errno</code> from <code>errno.h</code> .

Example

```
#include <stdio.h>
```

```
#include "18aiss8ao8_dsl.h"

int aiss8ao8_ioctl_dsl(int fd, int request, void *arg)
{
    int errs;
    int ret;

    ret = aiss8ao8_ioctl(fd, request, arg);

    if (ret)
        printf("ERROR: aiss8ao8_ioctl() returned %d\n", ret);

    errs = ret ? 1 : 0;
    return(errs);
}
```

4.6.4. aiss8ao8_open()

This function is the entry point to open a connection to an 18AISS8AO8 board. The device is initialized before the function returns.

Prototype

```
int aiss8ao8_open(int device, int share, int* fd);
```

Argument	Description						
device	This is the zero-based index of the 18AISS8AO8 to access. *						
share	Open the device in Shared Access Mode? If non-zero the device is opened in Shared Access Mode (see below). If zero the device is opened in Exclusive Access Mode (see below).						
fd	The device handle is returned here. The pointer cannot be NULL. Values returned are as follows. <table border="1" data-bbox="451 1178 1265 1276"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>>= 0</td> <td>This is the handle to use to access the device in subsequent calls.</td> </tr> <tr> <td>-1</td> <td>There was an error. The device is not accessible.</td> </tr> </tbody> </table>	Value	Description	>= 0	This is the handle to use to access the device in subsequent calls.	-1	There was an error. The device is not accessible.
Value	Description						
>= 0	This is the handle to use to access the device in subsequent calls.						
-1	There was an error. The device is not accessible.						

* If the index value is -1, then the API Library accesses /proc/18aiss8ao8.

Return Value	Description
0	The operation succeeded.
< 0	An error occurred. This is the negative of errno from errno.h.

Example

```
#include <stdio.h>

#include "18aiss8ao8_dsl.h"

int aiss8ao8_open_dsl(int device, int share, int* fd)
{
    int errs;
    int ret;

    ret = aiss8ao8_open(device, share, fd);
```

```

if (ret)
    printf("ERROR: aiss8ao8_open() returned %d\n", ret);

errs    = ret ? 1 : 0;
return(errs);
}

```

4.6.4.1. Access Modes

Shared Access Mode:

Shared Access Mode allows multiple applications to access the same device simultaneously. In this mode, the first successful open request returns with the device in an initialized state. Subsequent successful Shared Access Mode open requests do not affect the state of the device. Once opened in Shared Access Mode, the device access remains in this mode until all Shared Access Mode accesses release the device with a close request.

Exclusive Access Mode:

Exclusive Access Mode allows a single application to acquire exclusive access to a device. In this mode, a successful open request returns with the device in an initialized state. While open in this mode all subsequent open requests will fail regardless of the access mode requested. Once opened in Exclusive Access Mode, the device access remains in this mode until released by the application with a close request.

4.6.5. aiss8ao8_read()

This function is the entry point to reading data from an open 18AISS8AO8. This function should only be called after a successful open of the respective device. The function reads up to `bytes` bytes from the board. The return value is the number of bytes actually read.

NOTE: When performing an open on device index `-1`, the API Library accesses the `/proc/18aiss8ao8` text file. This read service then reads from that file. (See section 2.2, page 12.)

NOTE: For additional information please refer to the I/O Modes information (section 8.4, page 62).

Prototype

```
int aiss8ao8_read(int fd, void *dst, size_t bytes);
```

Argument	Description
<code>fd</code>	This is the file descriptor of the device to access.
<code>dst</code>	The data read will be put here.
<code>bytes</code>	This is the desired number of bytes to read. This must be a multiple of four (4).

Return Value	Description
0 to <code>bytes</code>	The operation succeeded. A value less than <code>bytes</code> indicates that the request timed out.
< 0	An error occurred. This is the negative of <code>errno</code> from <code>errno.h</code> .

Example

```

#include <stdio.h>

#include "18aiss8ao8_dsl.h"

```

```

int aiss8ao8_read_dsl(int fd, void* dst, size_t bytes, size_t* qty)
{
    int errs;
    int ret;

    ret = aiss8ao8_read(fd, dst, bytes);

    if (ret < 0)
        printf("ERROR: aiss8ao8_read() returned %d\n", ret);

    if (qty)
        qty[0] = (ret < 0) ? 0 : (size_t) ret;

    errs = (ret < 0) ? 1 : 0;
    return(errs);
}

```

4.6.6. aiss8ao8_write()

This function is the entry point to writing data to an open 18AISS8AO8. This function should only be called after a successful open of the respective device. The function writes up to `bytes` bytes to the board. The return value is the number of bytes actually written.

NOTE: When performing an open on device index `-1`, the API Library accesses the `/proc/18aiss8ao8` text file. In this instance, all write requests will fail.

Prototype

```
int aiss8ao8_write(int fd, const void *src, size_t bytes);
```

Argument	Description
<code>fd</code>	This is the file descriptor of the device to access.
<code>src</code>	This is the source for the data written to the device.
<code>bytes</code>	This is the desired number of bytes to write. This must be a multiple of four (4).

Return Value	Description
0 to <code>bytes</code>	The operation succeeded. A value less than <code>bytes</code> indicates that the request timed out.
< 0	An error occurred. This is the negative of <code>errno</code> from <code>errno.h</code> .

Example

```

#include <stdio.h>

#include "18aiss8ao8_dsl.h"

int aiss8ao8_write_dsl(int fd, const void* src, size_t bytes,
size_t* qty)
{
    int errs;
    int ret;

    ret = aiss8ao8_write(fd, src, bytes);
}

```

```

if (ret < 0)
    printf("ERROR: aiss8ao8_write() returned %d\n", ret);

if (qty)
    qty[0] = (ret < 0) ? 0 : (size_t) ret;

errs    = (ret < 0) ? 1 : 0;
return(errs);
}

```

4.7. IOCTL Services

The 18AISS8AO8 API Library and device driver implement the following IOCTL services. Each service is described along with the applicable `aiss8ao8_ioctl()` function arguments.

4.7.1. AISS8AO8_IOCTL_AI_BUF_CLEAR

This service immediately clears the current content from the input buffer. It also clears the input overrun status. This service does not halt input sampling.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_BUF_CLEAR
arg	Not used.

4.7.2. AISS8AO8_IOCTL_AI_BUF_LEVEL

This service returns the current number of 32-bit data items in the input buffer.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_BUF_LEVEL
arg	s32*

The value returned will be from zero to 512K or zero to 1M, depending on the depth of the installed buffers.

4.7.3. AISS8AO8_IOCTL_AI_BUF_OVERFLOW

This service operates on the Input Buffer Overflow status.

NOTE: This service always returns the current overflow status.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_BUF_OVERFLOW
arg	s32*

Valid argument values supplied to the service are as follows.

Value	Description
-1	Retrieve the current state.

AISS8AO8_BUF_OVERFLOW_CLEAR	Clear the overflow status.
AISS8AO8_BUF_OVERFLOW_TEST	Report the current status.

The current state is reported as one of the following values.

Value	Description
AISS8AO8_BUF_OVERFLOW_NO	The buffer has not experienced an overflow condition.
AISS8AO8_BUF_OVERFLOW_YES	The buffer has experienced an overflow condition.

4.7.4. AISS8AO8_IOCTL_AI_BUF_THR_LVL

This service configures the input buffer threshold level.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_BUF_THR_LVL
arg	s32*

Valid argument values are from zero to 0xFFFFF, and -1. A value of -1 will return the current threshold level setting.

4.7.5. AISS8AO8_IOCTL_AI_BUF_THR_STS

This service retrieves the current input buffer threshold level status, which indicates whether or not there are more than Threshold Level number of 32-bit data items in the input buffer.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_BUF_THR_STS
arg	s32*

The current status is reported as one of the following values.

Value	Description
AISS8AO8_BUF_THR_STS_CLEAR	The input buffer contains Threshold Level number of data items, or fewer.
AISS8AO8_BUF_THR_STS_SET	The input buffer contains more than Threshold Level number of data items.

4.7.6. AISS8AO8_IOCTL_AI_BUF_UNDERFLOW

This service operates on the Input Buffer Underflow status.

NOTE: When the underflow feature is supported, this service always returns the current underflow status.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_BUF_UNDERFLOW
arg	s32*

Valid argument values supplied to the service are as follows.

Value	Description
-1	Retrieve the current state.
AISS8A08_AI_BUF_UNDERFLOW_CLEAR	Clear the underflow status.
AISS8A08_AI_BUF_UNDERFLOW_TEST	Report the current status.

The current state is reported as one of the following values.

Value	Description
-1	The input buffer underflow feature is unsupported.
AISS8A08_AI_BUF_UNDERFLOW_NO	The buffer has not experienced an underflow condition.
AISS8A08_AI_BUF_UNDERFLOW_YES	The buffer has experienced an underflow condition.

4.7.7. AISS8A08_IOCTL_AI_BURST_ENABLE

This service enables and disables input bursting.

Usage

Argument	Description
request	AISS8A08_IOCTL_AI_BURST_ENABLE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8A08_BURST_ENABLE_NO	This option disables input bursting.
AISS8A08_BURST_ENABLE_YES	This option enables input bursting.

4.7.8. AISS8A08_IOCTL_AI_BURST_SIZE

This service configures the size of a single input burst (the count is in scans, which is an A/D conversion of all active input channels).

Usage

Argument	Description
request	AISS8A08_IOCTL_AI_BURST_SIZE
arg	s32*

Valid argument values are from zero to 0xFFFFFFFF, or -1 to retrieve the current setting.

4.7.9. AISS8A08_IOCTL_AI_BURST_STATUS

This service reports on the board's input burst status.

Usage

Argument	Description
request	AISS8A08_IOCTL_AI_BURST_STATUS
arg	s32*

The value returned will be one of the following.

Value	Description
AISS8AO8_AI_BURST_STATUS_BUSY	The board is not ready to start an input burst operation.
AISS8AO8_AI_BURST_STATUS_READY	The board is ready to start an input burst operation.

4.7.10. AISS8AO8_IOCTL_AI_CHAN_SEL

This service configures the set of active input channels. If a bit is set, then that channel is enabled. If a bit is clear, then that channel is disabled.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_CHAN_SEL
arg	s32*

Valid argument values are from zero to 0xFF, for four channel boards, from zero to 0xF, for four channel boards, or -1 to retrieve the current setting.

4.7.11. AISS8AO8_IOCTL_AI_CLK_TRIG_OUT

This service configures the operation analog input clock and trigger signals that appear at the cable interface.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_CLK_TRIG_OUT
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_AI_CLK_TRIG_OUT_DRIVE	The signals are driven.
AISS8AO8_AI_CLK_TRIG_OUT_OFF	The signals are disabled.

4.7.12. AISS8AO8_IOCTL_AI_CLOCK_SRC

This service configures the analog input clock source selection.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_CLOCK_SRC
arg	s32*

The value returned will be one of the following.

Value	Description
AISS8AO8_AI_CLOCK_SRC_EXT	This selects a user supplied clock source provided at the cable interface.
AISS8AO8_AI_CLOCK_SRC_RAG	This selects the Rate-A Generator.
AISS8AO8_AI_CLOCK_SRC_RCG	This selects the Rate-C Generator.

4.7.13. AISS8AO8_IOCTL_AI_ENABLE

This service enables or disables Analog Input sampling.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_ENABLE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_AIO_ENABLE_NO	This disables input sampling.
AISS8AO8_AIO_ENABLE_YES	This enables input samplings.

4.7.14. AISS8AO8_IOCTL_AI_GRP_A_FILTER

This service configures the filter selection for channel group A.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_GRP_A_FILTER
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_AI_GRP_FILTER_A	This selects Filter-A.
AISS8AO8_AI_GRP_FILTER_B	This selects Filter-B.
AISS8AO8_AI_GRP_FILTER_NONE	This disables any filter selectin.

4.7.15. AISS8AO8_IOCTL_AI_GRP_B_FILTER

This service configures the filter selection for channel group B.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_GRP_B_FILTER
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_AI_GRP_FILTER_A	This selects Filter-A.
AISS8AO8_AI_GRP_FILTER_B	This selects Filter-B.
AISS8AO8_AI_GRP_FILTER_NONE	This disables any filter selectin.

4.7.16. AISS8AO8_IOCTL_AI_I_LOOP_TERM

This service configures the selection of channels that have current loop termination enabled.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_I_LOOP_TERM
arg	s32*

Valid argument values are from zero to 0xFF for eight channels, from zero to 0xF for four channel boards, and -1 to retrieve the current setting.

4.7.17. AISS8AO8_IOCTL_AI_MODE

This service configures the board's Analog Input Mode.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_MODE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_AI_MODE_AO_0_HI	Route the high side of output channel 0 to the inputs.
AISS8AO8_AI_MODE_AO_0_LO	Route the low side of output channel 0 to the inputs.
AISS8AO8_AI_MODE_AO_1_HI	Route the high side of output channel 1 to the inputs.
AISS8AO8_AI_MODE_AO_1_LO	Route the low side of output channel 1 to the inputs.
AISS8AO8_AI_MODE_AO_2_HI	Route the high side of output channel 2 to the inputs.
AISS8AO8_AI_MODE_AO_2_LO	Route the low side of output channel 2 to the inputs.
AISS8AO8_AI_MODE_AO_3_HI	Route the high side of output channel 3 to the inputs.
AISS8AO8_AI_MODE_AO_3_LO	Route the low side of output channel 3 to the inputs.
AISS8AO8_AI_MODE_AO_4_LO	Route the high side of output channel 4 to the inputs.
AISS8AO8_AI_MODE_AO_4_HI	Route the high side of output channel 4 to the inputs.
AISS8AO8_AI_MODE_AO_5_LO	Route the high side of output channel 5 to the inputs.
AISS8AO8_AI_MODE_AO_5_HI	Route the high side of output channel 5 to the inputs.
AISS8AO8_AI_MODE_AO_6_HI	Route the high side of output channel 6 to the inputs.
AISS8AO8_AI_MODE_AO_6_LO	Route the high side of output channel 6 to the inputs.
AISS8AO8_AI_MODE_AO_7_HI	Route the high side of output channel 7 to the inputs.
AISS8AO8_AI_MODE_AO_7_LO	Route the high side of output channel 7 to the inputs.
AISS8AO8_AI_MODE_DIFF	Configure the input channels for differential operation.
AISS8AO8_AI_MODE_SINGLE	Configure the input channels for single-ended operation.
AISS8AO8_AI_MODE_VREF	Configure the input channels for +VREF input testing
AISS8AO8_AI_MODE_ZERO	Configure the input channels for Zero input testing

4.7.18. AISS8AO8_IOCTL_AI_RANGE

This service configures the analog input voltage range.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_RANGE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_RANGE_0_5V	Set the input voltage range to zero to +5 volts.
AISS8AO8_RANGE_0_10V	Set the input voltage range to zero to 10 volts.
AISS8AO8_RANGE_2_5V	Set the input voltage range to ± 2.5 volts.
AISS8AO8_RANGE_5V	Set the input voltage range to ± 5 volts.
AISS8AO8_RANGE_10V	Set the input voltage range to ± 10 volts.

4.7.19. AISS8AO8_IOCTL_AI_SW_CLOCK

This service initiates a manual clock cycle for input sampling. The driver returns immediately and does not wait for completion.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_SW_CLOCK
arg	Not used.

4.7.20. AISS8AO8_IOCTL_AI_SW_TRIGGER

This service initiates a manual trigger cycle for input bursting. The driver returns immediately and does not wait for completion.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_SW_TRIGGER
arg	Not used.

4.7.21. AISS8AO8_IOCTL_AI_TRIG_SRC

This service configures the analog input burst clocking source.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AI_TRIG_SRC
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_AI_TRIG_SRC_EXT	This selects the external trigger input.
AISS8AO8_AI_TRIG_SRC_RBG	This selects the rate-B Generator.

AISS8AO8_AI_TRIG_SRC_RDG	This selects the rate-D Generator.
--------------------------	------------------------------------

4.7.22. AISS8AO8_IOCTL_AO_BUF_CLEAR

This service immediately clears the current content from the output buffer. It also clears the output data and frame overrun status.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_BUF_CLEAR
arg	Not used.

4.7.23. AISS8AO8_IOCTL_AO_BUF_EMPTY

This service reports on the output buffer's empty state.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_BUF_EMPTY
arg	s32*

The current status is reported as one of the following values.

Value	Description
AISS8AO8_AO_BUFFER_EMPTY_NO	The output buffer is not empty.
AISS8AO8_AO_BUFFER_EMPTY_YES	The output buffer is empty.

4.7.24. AISS8AO8_IOCTL_AO_BUF_FULL

This service reports on the output buffer's full state.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_BUF_FULL
arg	s32*

The current status is reported as one of the following values.

Value	Description
AISS8AO8_AO_BUFFER_FULL_NO	The output buffer is not full.
AISS8AO8_AO_BUFFER_FULL_YES	The output buffer is full.

4.7.25. AISS8AO8_IOCTL_AO_BUF_LEVEL

This service returns the current number of 32-bit data items in the output buffer.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_BUF_LEVEL
arg	s32*

The value returned will be from zero to 512K or zero to 1M, depending on the size of the output buffer.

4.7.26. AISS8AO8_IOCTL_AO_BUF_LOAD_REQ

This service requests load access to the output buffer. The driver waits for access to be granted. The waiting period limit is the current Tx I/O timeout period.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_BUF_LOAD_REQ
arg	Not used.

4.7.27. AISS8AO8_IOCTL_AO_BUF_LOAD_STS

This service retrieves the output buffer load access status.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_BUF_LOAD_STS
arg	s32*

The current status is reported as one of the following values.

Value	Description
AISS8AO8_BUF_LOAD_STS_NOT_READY	The output buffer is not yet accessible.
AISS8AO8_BUF_LOAD_STS_READY	The output buffer is available for output data.

4.7.28. AISS8AO8_IOCTL_AO_BUF_MODE

This service operates on the output buffer operating mode.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_BUF_MODE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_BUF_MODE_CIRC	After data exits the buffer, it is routed back into the buffer.
AISS8AO8_BUF_MODE_OPEN	Data is not routed back into the output buffer.

4.7.29. AISS8AO8_IOCTL_AO_BUF_OVER_DATA

This service operates on the output buffer data overflow status.

NOTE: This service always returns the current data overflow status.

Usage

Argument	Description
request	AISS8A08_IOCTL_AO_BUF_OVER_DATA
arg	s32*

Valid argument values supplied to the service are as follows.

Value	Description
-1	Retrieve the current state.
AISS8A08_BUF_OVERFLOW_CLEAR	Clear the overflow status.
AISS8A08_BUF_OVERFLOW_TEST	Report the current status.

The current state is reported as one of the following values.

Value	Description
AISS8A08_BUF_OVERFLOW_NO	The buffer has not experienced an overflow condition.
AISS8A08_BUF_OVERFLOW_YES	The buffer has experienced an overflow condition.

4.7.30. AISS8A08_IOCTL_AO_BUF_OVER_FRAM

This service operates on the output buffer frame overflow status.

NOTE: This service always returns the current frame overflow status.

Usage

Argument	Description
request	AISS8A08_IOCTL_AO_BUF_OVER_FRAM
arg	s32*

Valid argument values supplied to the service are as follows.

Value	Description
-1	Retrieve the current state.
AISS8A08_BUF_OVERFLOW_CLEAR	Clear the overflow status.
AISS8A08_BUF_OVERFLOW_TEST	Report the current status.

The current state is reported as one of the following values.

Value	Description
AISS8A08_BUF_OVERFLOW_NO	The buffer has not experienced an overflow condition.
AISS8A08_BUF_OVERFLOW_YES	The buffer has experienced an overflow condition.

4.7.31. AISS8A08_IOCTL_AO_BUF_THR_LVL

This service configures the output buffer threshold level.

Usage

Argument	Description
request	AISS8A08_IOCTL_AO_BUF_THR_LVL
arg	s32*

Valid argument values are from zero to 0xFFFFF, and -1. A value of -1 will return the current threshold level setting.

4.7.32. AISS8AO8_IOCTL_AO_BUF_THR_STS

This service retrieves the current output buffer threshold level status, which indicates whether or not there are more than Threshold Level number of 32-bit data items in the output buffer.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_BUF_THR_STS
arg	s32*

The current status is reported as one of the following values.

Value	Description
AISS8AO8_BUF_THR_STS_CLEAR	The output buffer contains Threshold Level number of data items, or fewer.
AISS8AO8_BUF_THR_STS_SET	The output buffer contains more than Threshold Level number of data items.

4.7.33. AISS8AO8_IOCTL_AO_BURST_ENABLE

This service enables or disables output bursting.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_BURST_ENABLE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_BURST_ENABLE_NO	This option disables input bursting.
AISS8AO8_BURST_ENABLE_YES	This option enables input bursting.

4.7.34. AISS8AO8_IOCTL_AO_BURST_STATUS

This service reports on the board's output burst readiness status.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_BURST_STATUS
arg	s32*

The value returned will be one of the following.

Value	Description
AISS8AO8_BURST_STATUS_BUSY	The board is not ready to start an output burst operation.
AISS8AO8_BURST_STATUS_READY	The board is ready to start an output burst operation.

4.7.35. AISS8AO8_IOCTL_AO_CHAN_SEL

This service configures the set of active output channels. If a bit is set, then that channel is enabled. If a bit is clear, then that channel is disabled.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_CHAN_SEL
arg	s32*

Valid argument values are from zero to 0xFF, for eight channel boards, from zero to 0xF, for four channel boards, or -1 to retrieve the current setting.

4.7.36. AISS8AO8_IOCTL_AO_CLK_TRIG_OUT

This service configures the board's analog output trigger that appears at the cable interface.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_CLK_TRIG_OUT
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_AO_CLK_TRIG_OUT_DRIVE	The signal is driven.
AISS8AO8_AO_CLK_TRIG_OUT_OFF	The signal is disabled.

4.7.37. AISS8AO8_IOCTL_AO_CLOCK_READY

This service reports the analog output functionality's readiness for being clocked.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_CLOCK_READY
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_CLOCK_READY_NO	The board will not respond to an output clock.
AISS8AO8_CLOCK_READY_YES	The board will respond to an output clock.

4.7.38. AISS8AO8_IOCTL_AO_CLOCK_SRC

This service configures the source for the output sample clock.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_CLOCK_SRC
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_AO_CLOCK_SRC_EXT	The clock source is provided by an external source.
AISS8AO8_AO_CLOCK_SRC_RAG	The clocking source is the Rate-A Generator.
AISS8AO8_AO_CLOCK_SRC_RCG	The clocking source is the Rate-C Generator.

4.7.39. AISS8AO8_IOCTL_AO_ENABLE

This service enables or disables output sampling.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_ENABLE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_AIO_ENABLE_NO	This disables output sampling.
AISS8AO8_AIO_ENABLE_YES	This enables output samplings.

4.7.40. AISS8AO8_IOCTL_AO_MODE

This service configures the board's analog output mode.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_MODE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_AO_MODE_DIFF	The outputs are configured for differential operation.
AISS8AO8_AO_MODE_SINGLE	The outputs are configured for single-ended operation.

4.7.41. AISS8AO8_IOCTL_AO_OUTPUT_MODE

This service configures the timing of how output data appears at the cable interface.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_OUTPUT_MODE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_AO_OUTPUT_MODE_IMMED	The output appears immediately.
AISS8AO8_AO_OUTPUT_MODE_SIMUL	Output for all active channels appears simultaneously.

4.7.42. AISS8AO8_IOCTL_AO_RANGE

This service configures the analog output voltage range.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_RANGE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_RANGE_0_5V	Set the output voltage range zero to +5 volts.
AISS8AO8_RANGE_0_10V	Set the output voltage range zero to +10 volts.
AISS8AO8_RANGE_2_5V	Set the output voltage range to ± 2.5 volts.
AISS8AO8_RANGE_5V	Set the output voltage range to ± 5 volts.
AISS8AO8_RANGE_10V	Set the output voltage range to ± 10 volts.

4.7.43. AISS8AO8_IOCTL_AO_SW_CLOCK

This service initiates a manual clock cycle for output sampling. The driver returns immediately and does not wait for completion.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_SW_CLOCK
arg	Not used.

4.7.44. AISS8AO8_IOCTL_AO_SW_TRIGGER

This service initiates a manual trigger cycle for output bursting. The driver returns immediately and does not wait for completion.

Usage

Argument	Description
request	AISS8AO8_IOCTL_AO_SW_TRIGGER
arg	Not used.

4.7.45. AISS8A08_IOCTL_AO_TRIG_SRC

This service configures the analog output trigger clocking source.

Usage

Argument	Description
request	AISS8A08_IOCTL_AO_TRIG_SRC
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8A08_AO_TRIG_SRC_EXT	The trigger clock is provided externally at the cable interface.
AISS8A08_AO_TRIG_SRC_RBG	The trigger clock is provided by the Rate-B Generator.
AISS8A08_AO_TRIG_SRC_RDG	The trigger clock is provided by the Rate-D Generator.

4.7.46. AISS8A08_IOCTL_AUTO_CAL_STS

This service reports the status of the most recent auto-calibration cycle.

Usage

Argument	Description
request	AISS8A08_IOCTL_AUTO_CAL_STS
arg	s32*

The current status is reported as one of the following values.

Value	Description
AISS8A08_AUTO_CAL_STS_ACTIVE	Auto-calibration is in progress.
AISS8A08_AUTO_CAL_STS_FAIL	Auto-calibration failed.
AISS8A08_AUTO_CAL_STS_PASS	Auto-calibration passed.

4.7.47. AISS8A08_IOCTL_AUTO_CALIBRATE

This service initiates an auto-calibration cycle. Most configuration settings should be made before running an auto-calibration cycle. The driver waits for the operation to complete before returning.

NOTE: If the auto-calibration service returns an error status, an error message will be posted to the system log briefly describing the error condition.

Usage

Argument	Description
request	AISS8A08_IOCTL_AUTO_CALIBRATE
arg	Not used.

4.7.48. AISS8A08_IOCTL_DATA_FORMAT

This service sets the data encoding format.

Usage

Argument	Description
request	AISS8A08_IOCTL_DATA_FORMAT
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8A08_DATA_FORMAT_2S_COMP	Select the Twos Compliment data format.
AISS8A08_DATA_FORMAT_OFF_BIN	Select the Offset Binary encoding format.

4.7.49. AISS8A08_IOCTL_DIO_DIR_OUT

This service configures the direction of the digital I/O cable signals. If a bit is set in the bitmap value, then that digital I/O byte's signals are outputs. The signals are otherwise inputs. Bit position zero corresponds to the byte zero signals.

Usage

Argument	Description
request	AISS8A08_IOCTL_DIO_DIR_OUT
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8A08_DIO_DIR_OUT_HI_IN_LO_IN	Both nibbles are inputs.
AISS8A08_DIO_DIR_OUT_HI_IN_LO_OT	The low nibble is output and the high nibble is input.
AISS8A08_DIO_DIR_OUT_HI_OT_LO_IN	The low nibble is input and the high nibble is output.
AISS8A08_DIO_DIR_OUT_HI_OT_LO_OT	Both nibbles are outputs.

4.7.50. AISS8A08_IOCTL_DIO_READ

This service retrieves the signal levels for the 16 digital I/O lines. Bit position zero corresponds to signal zero.

Usage

Argument	Description
request	AISS8A08_IOCTL_DIO_READ
arg	s32*

Argument values returned are from zero to 0xFF.

4.7.51. AISS8A08_IOCTL_DIO_WRITE

This service applies values to the digital I/O cable signals. The value written is retained even for those signals configured as inputs. Bit position zero corresponds to signal zero.

Usage

Argument	Description
request	AISS8A08_IOCTL_DIO_WRITE
arg	s32*

Valid argument values are from zero to 0xFF, or -1 to retrieve the current setting.

4.7.52. AISS8A08_IOCTL_GEN_A_ENABLE

This service enables or disables Rate-A Generator.

Usage

Argument	Description
request	AISS8A08_IOCTL_GEN_A_ENABLE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8A08_GEN_ENABLE_NO	This option disables the rate generator.
AISS8A08_GEN_ENABLE_YES	This option enables the rate generator.

4.7.53. AISS8A08_IOCTL_GEN_A_NDIV

This service sets the Rate-A Generator NDIV divider value.

Usage

Argument	Description
request	AISS8A08_IOCTL_GEN_A_NDIV
arg	s32*

Valid argument values are in the range from 80 to 0xFFFFFFFF, and -1. The value -1 is used to retrieve the current setting.

4.7.54. AISS8A08_IOCTL_GEN_B_ENABLE

This service enables or disables Rate-B Generator.

Usage

Argument	Description
request	AISS8A08_IOCTL_GEN_B_ENABLE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8A08_GEN_ENABLE_NO	This option disables the rate generator.
AISS8A08_GEN_ENABLE_YES	This option enables the rate generator.

4.7.55. AISS8AO8_IOCTL_GEN_B_NDIV

This service sets the Rate-B Generator NDIV divider value.

Usage

Argument	Description
request	AISS8AO8_IOCTL_GEN_B_NDIV
arg	s32*

Valid argument values are in the range from 80 to 0xFFFFFFFF, and -1. The value -1 is used to retrieve the current setting.

4.7.56. AISS8AO8_IOCTL_GEN_C_ENABLE

This service enables or disables Rate-C Generator.

Usage

Argument	Description
request	AISS8AO8_IOCTL_GEN_C_ENABLE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_GEN_ENABLE_NO	This option disables the rate generator.
AISS8AO8_GEN_ENABLE_YES	This option enables the rate generator.

4.7.57. AISS8AO8_IOCTL_GEN_C_NDIV

This service sets the Rate-C Generator NDIV divider value.

Usage

Argument	Description
request	AISS8AO8_IOCTL_GEN_C_NDIV
arg	s32*

Valid argument values are in the range from 80 to 0xFFFFFFFF, and -1. The value -1 is used to retrieve the current setting.

4.7.58. AISS8AO8_IOCTL_GEN_D_ENABLE

This service enables or disables Rate-D Generator.

Usage

Argument	Description
request	AISS8AO8_IOCTL_GEN_D_ENABLE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8A08_GEN_ENABLE_NO	This option disables the rate generator.
AISS8A08_GEN_ENABLE_YES	This option enables the rate generator.

4.7.59. AISS8A08_IOCTL_GEN_D_NDIV

This service sets the Rate-D Generator NDIV divider value.

Usage

Argument	Description
request	AISS8A08_IOCTL_GEN_C_NDIV
arg	s32*

Valid argument values are in the range from 80 to 0xFFFFFFFF, and -1. The value -1 is used to retrieve the current setting.

4.7.60. AISS8A08_IOCTL_INITIALIZE

This service returns all driver interface settings for the board to the state they were in when the board was first opened. This includes both hardware-based settings and software-based settings.

NOTE: If the initialization service returns an error status, an error message will be posted to the system log briefly describing the error condition.

Usage

Argument	Description
request	AISS8A08_IOCTL_INITIALIZE
arg	Not used.

4.7.61. AISS8A08_IOCTL_IRQ_ENABLE

This service configures enabling and disabling of device interrupts. If a bit is set, then the interrupt is enabled. If a bit is clear, then the interrupt is disabled.

Usage

Argument	Description
request	AISS8A08_IOCTL_IRQ_ENABLE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8A08_IRQ_AI_CLOCK	This refers to the analog input clock.
AISS8A08_IRQ_AI_BURST_DONE	This refers to the completion of an analog input burst.
AISS8A08_IRQ_AI_BURST_START	This refers to the beginning of an analog input burst.
AISS8A08_IRQ_AI_FAULT	This refers to an input buffer overflow.
AISS8A08_IRQ_AI_THRESH_H2L	This refers to a low to high transition of the analog input threshold level status.
AISS8A08_IRQ_AI_THRESH_L2H	This refers to a high to low transition of the analog input

	threshold level status.
AISS8A08_IRQ_AO_BURST_READY	This refers to readiness of the board to begin an analog output burst.
AISS8A08_IRQ_AO_CLOCK	This refers to the analog output clock.
AISS8A08_IRQ_AO_FAULT	This refers to an analog output buffer underflow, or to a data or frame overflow.
AISS8A08_IRQ_AO_LOAD_RDY_H2L	This refers to a high to low transition of the output buffer's Load Ready status.
AISS8A08_IRQ_AO_LOAD_RDY_L2H	This refers to a low to high transition of the output buffer's Load Ready status.
AISS8A08_IRQ_AO_THRESH_H2L	This refers to a high to low transition of the output buffer's threshold level status.
AISS8A08_IRQ_AO_THRESH_L2H	This refers to a low to high transition of the output buffer's threshold level status.
AISS8A08_IRQ_AUTO_CAL_DONE	This refers to the completion of an auto-calibration cycle.
AISS8A08_IRQ_DIO_0_L2H	This refers to a low to high transition at digital I/O signal D0.

4.7.62. AISS8A08_IOCTL_QUERY

This service queries the driver for various pieces of information about the board and the driver.

Usage

Argument	Description
request	AISS8A08_IOCTL_QUERY
arg	s32*

Valid argument values are as follows.

Value	Description
AISS8A08_QUERY_AI_UNDERFLOW	This returns one if underflow is supported and zero if not.
AISS8A08_QUERY_AUTO_CAL_MS	This returns the maximum duration of the Auto Calibration cycle in milliseconds.
AISS8A08_QUERY_CHANNEL_AI_MAX	This returns the maximum number of input channels supported by the board, which may be more than the board's current configuration.
AISS8A08_QUERY_CHANNEL_AI_QTY	This returns the actual number of input channels on the current board. If the value returned is -1, then the driver was unable to determine the number of channels.
AISS8A08_QUERY_CHANNEL_AO_MAX	This returns the maximum number of output channels supported by the board, which may be more than the board's current configuration.
AISS8A08_QUERY_CHANNEL_AO_QTY	This returns the actual number of output channels on the current board. If the value returned is -1, then the driver was unable to determine the number of channels.
AISS8A08_QUERY_COUNT	This returns the number of query options supported by the IOCTL service.
AISS8A08_QUERY_DEVICE_TYPE	This returns one if Demand Mode DMA is supported and zero if not.
AISS8A08_QUERY_DMDMA	This returns the identifier value for the board's type. This should be GSC_DEV_TYPE_18AISS8A08.
AISS8A08_QUERY_FIFO_SIZE_RX	This returns the size of the input buffer in 32-bit A/D values.

AISS8A08_QUERY_FIFO_SIZE_TX	This returns the size of the output buffer in 32-bit D/A values.						
AISS8A08_QUERY_FILTER_A	This gives the filter frequency of input filter A. <table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>-1</td> <td>The filter frequency is unknown.</td> </tr> <tr> <td>80000</td> <td>The filter frequency is 80KHz.</td> </tr> </tbody> </table>	Value	Description	-1	The filter frequency is unknown.	80000	The filter frequency is 80KHz.
Value	Description						
-1	The filter frequency is unknown.						
80000	The filter frequency is 80KHz.						
AISS8A08_QUERY_FILTER_B	This gives the filter frequency of input filter B. <table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>-1</td> <td>The filter frequency is unknown.</td> </tr> <tr> <td>200000</td> <td>The filter frequency is 200KHz.</td> </tr> </tbody> </table>	Value	Description	-1	The filter frequency is unknown.	200000	The filter frequency is 200KHz.
Value	Description						
-1	The filter frequency is unknown.						
200000	The filter frequency is 200KHz.						
AISS8A08_QUERY_FSAMP_MAX	This gives the maximum FSAMP value in S/S for both input and output channels.						
AISS8A08_QUERY_FSAMP_MIN	This gives the minimum FSAMP value in S/S for both input and output channels.						
AISS8A08_QUERY_INIT_MS	This returns the duration of a board initialization in milliseconds.						
AISS8A08_QUERY_MASTER_CLOCK	This returns the master clock frequency in hertz.						
AISS8A08_QUERY_NDIV_MAX	This gives the maximum NDIV divider value for the rate generator.						
AISS8A08_QUERY_NDIV_MIN	This gives the minimum NDIV divider value for the rate generator.						

Valid return values are as indicated in the above table and as given in the below table.

Value	Description
AISS8A08_IOCTL_QUERY_ERROR	Either there was a processing error or the query option is unrecognized.

4.7.63. AISS8A08_IOCTL_REG_MOD

This service performs a read-modify-write of an 18AISS8A08 register. This includes only the GSC firmware registers. The PCI and PLX Feature Set Registers are read-only. Refer to `18aiss8a08.h` for the complete list of GSC firmware registers.

Usage

Argument	Description
request	AISS8A08_IOCTL_REG_MOD
arg	gsc_reg_t*

Definition

```
typedef struct
{
    u32 reg;
    u32 value;
    u32 mask;
} gsc_reg_t;
```

Fields	Description
reg	This is set to the identifier for the register to access.
value	This contains the value for the register bits to modify.
mask	This specifies the set of bits to modify. If a bit here is set, then the respective register bits is modified. If a bit here is zero, then the respective register bit is unmodified.

4.7.64. AISS8AO8_IOCTL_REG_READ

This service reads the value of an 18AISS8AO8 register. This includes the PCI registers, the PLX Feature Set Registers and the GSC firmware registers. Refer to `18aiiss8ao8.h` and `gsc_pci9056.h` for the complete list of accessible registers.

Usage

Argument	Description
request	AISS8AO8_IOCTL_REG_READ
arg	<code>gsc_reg_t*</code>

Definition

```
typedef struct
{
    u32 reg;
    u32 value;
    u32 mask;
} gsc_reg_t;
```

Fields	Description
reg	This is set to the identifier for the register to access.
value	This is the value read from the specified register.
mask	This is ignored for read request.

4.7.65. AISS8AO8_IOCTL_REG_WRITE

This service writes a value to an 18AISS8AO8 register. This includes only the GSC firmware registers. The PCI and PLX Feature Set Registers are read-only. Refer to `18aiiss8ao8.h` for a complete list of the GSC firmware registers.

Usage

Argument	Description
request	AISS8AO8_IOCTL_REG_WRITE
arg	<code>gsc_reg_t*</code>

Definition

```
typedef struct
{
    u32 reg;
    u32 value;
    u32 mask;
} gsc_reg_t;
```

Fields	Description
reg	This is set to the identifier for the register to access.
value	This is the value to write to the specified register.
mask	This is ignored for write request.

4.7.66. AISS8A08_IOCTL_RX_IO_ABORT

This service aborts an ongoing read request.

Usage

Argument	Description
request	AISS8A08_IOCTL_RX_IO_ABORT
arg	s32*

The results are reported as one of the following values.

Value	Description
AISS8A08_IOCTL_RX_IO_ABORT_NO	A read request was not aborted as none were ongoing.
AISS8A08_IOCTL_RX_IO_ABORT_YES	An ongoing read request was aborted.

4.7.67. AISS8A08_IOCTL_RX_IO_MODE

This service sets the I/O mode used for data read requests.

Usage

Argument	Description
request	AISS8A08_IOCTL_RX_IO_MODE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
GSC_IOCTL_RX_IO_MODE_BMDMA	Use Block Mode DMA.
GSC_IOCTL_RX_IO_MODE_DMDMA	Use Demand Mode DMA (transfer data as it becomes possible to do so).
GSC_IOCTL_RX_IO_MODE_PIO	Use PIO mode, which is repetitive register access. This is the default.

4.7.68. AISS8A08_IOCTL_RX_IO_OVERFLOW

This service configures the read service to check for an input buffer overflow before performing read operations. Sampled data is lost when there is an overflow. If the check is performed and an overflow is detected, then the read service immediately returns an error.

NOTE: The check for an overflow is performed upon entry to the read service. The read service does not check for overflows that occur while the read is in progress. For in-progress overflows an application must perform the check manually or wait for the check performed by a subsequent read request.

Usage

Argument	Description
request	AISS8A08_IOCTL_RX_IO_OVERFLOW
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8A08_IOCTL_OVERFLOW_CHECK	Perform the check. This is the default.
AISS8A08_IOCTL_OVERFLOW_IGNORE	Do not perform the check.

4.7.69. AISS8A08_IOCTL_RX_IO_TIMEOUT

This service sets the timeout limit for read requests. The value is expressed in seconds.

Usage

Argument	Description
request	AISS8A08_IOCTL_RX_IO_TIMEOUT
arg	s32*

Valid argument values are in the range from zero to 3600, -1, and AISS8A08_IOCTL_TIMEOUT_INFINITE. A value of zero tells the driver not to sleep in order to wait for more data, and should only be used with PIO mode reads. A value of -1 is used to retrieve the current setting. If the option AISS8A08_IOCTL_TIMEOUT_INFINITE is used, then the driver will wait indefinitely rather than timing out. The default is 10 seconds.

4.7.70. AISS8A08_IOCTL_RX_IO_UNDERFLOW

This option configures the read service to check for an input buffer underflow before performing read operations. Indeterminate data is returned when there is an underflow. If the check is performed and an underflow is detected, then the read service immediately returns an error.

NOTE: The check for an underflow is performed upon entry to the read service. The read service does not check for underflows that occur while the read is in progress. For in-progress overflows an application must perform the check manually or wait for the check performed by a subsequent read request.

NOTE: If the input buffer underflow feature is unsupported, then this setting ignored by the read service.

Usage

Argument	Description
request	AISS8A08_IOCTL_RX_IO_UNDERFLOW
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8A08_IOCTL_UNDERFLOW_CHECK	Perform the check. This is the default.
AISS8A08_IOCTL_UNDERFLOW_IGNORE	Do not perform the check.

4.7.71. AISS8AO8_IOCTL_TX_IO_ABORT

This service aborts an ongoing `aiiss8ao8_write()` request.

Usage

Argument	Description
request	AISS8AO8_IOCTL_TX_IO_ABORT
arg	s32*

The results are reported as one of the following values.

Value	Description
AISS8AO8_IOCTL_TX_IO_ABORT_NO	An <code>aiiss8ao8_write()</code> request was not aborted as none were ongoing.
AISS8AO8_IOCTL_TX_IO_ABORT_YES	An ongoing <code>aiiss8ao8_write()</code> request was aborted.

4.7.72. AISS8AO8_IOCTL_TX_IO_MODE

This service sets the I/O mode used for data write requests.

Usage

Argument	Description
request	AISS8AO8_IOCTL_TX_IO_MODE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
GSC_IOCTL_TX_IO_MODE_BMDMA	Use Block Mode DMA.
GSC_IOCTL_TX_IO_MODE_PIO	Use PIO mode, which is repetitive register access. This is the default.

4.7.73. AISS8AO8_IOCTL_TX_IO_OVERFLOW

This service configures the write service to check for an output buffer overflow and an output frame overflow before performing write operations. Sampled data is lost when there is an overflow. If the check is performed and an overflow is detected, then the write service immediately returns an error.

NOTE: The check for an overflow is performed upon entry to the write service. The write service does not check for overflows that occur while the write is in progress. For in-progress overflows an application must perform the check manually or wait for the check performed by a subsequent write request.

Usage

Argument	Description
request	AISS8AO8_IOCTL_TX_IO_OVERFLOW
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8A08_IO_OVERFLOW_CHECK	Perform the check. This is the default.
AISS8A08_IO_OVERFLOW_IGNORE	Do not perform the check.

4.7.74. AISS8A08_IOCTL_TX_IO_TIMEOUT

This service sets the timeout limit for write requests. The value is expressed in seconds.

Usage

Argument	Description
request	AISS8A08_IOCTL_TX_IO_TIMEOUT
arg	s32*

Valid argument values are in the range from zero to 3600, -1, and AISS8A08_IO_TIMEOUT_INFINITE. A value of zero tells the driver not to sleep in order to wait for more space, and should only be used with PIO mode reads. A value of -1 is used to retrieve the current setting. If the option AISS8A08_IO_TIMEOUT_INFINITE is used, then the driver will wait indefinitely rather than timing out. The default is 10 seconds.

4.7.75. AISS8A08_IOCTL_WAIT_CANCEL

This service resumes all threads blocked via AISS8A08_IOCTL_WAIT_EVENT IOCTL calls (section 4.7.76, page 51), according to the provided criteria. When a blocked thread is waiting for any event specified in the structure, then the thread is resumed.

NOTE: The driver itself makes use of the wait services for various internal operations. Driver initiated waits are unaffected by application cancel requests.

Usage

Argument	Description
request	AISS8A08_IOCTL_WAIT_CANCEL
arg	gsc_wait_t*

Definition

```
typedef struct
{
    u32  flags;
    u32  main;
    u32  gsc;
    u32  alt;
    u32  io;
    u32  timeout_ms;
    u32  count;
} gsc_wait_t;
```

Fields	Description
flags	This is unused by wait cancel operations.
main	This specifies the set of GSC_WAIT_MAIN_* events whose wait requests are to be cancelled. Refer to section 4.7.76.2 on page 52.
gsc	This specifies the set of AISS8A08_WAIT_GSC_* events whose wait requests are to be cancelled. Refer to section 4.7.76.3 on page 52.

alt	This is unused by the 18AISS8AO8 driver and should be zero.
io	This specifies the set of AISS9AO8_WAIT_IO_* events whose wait requests are to be cancelled. Refer to section 4.7.76.4 on page 53.
timeout_ms	This is unused by wait cancel operations.
count	Upon return this indicates the number of waits that were cancelled.

4.7.76. AISS8AO8_IOCTL_WAIT_EVENT

This service blocks a thread until any one of a specified set of events occurs, or until a timeout lapses, whichever occurs first. The set of possible events to wait for are specified in the structure's main, gsc, alt and io fields. All field values must be valid and at least one event must be specified. If the thread is resumed because one of the referenced events has occurred, then the bit for the respective event is the only event bit that will be set. All other event bits and fields will be zero. (Multiple event bits will be set only if the events occur simultaneously.)

NOTE: The service waits only for the first of the specified events, not for all specified events.

NOTE: A wait timeout is reported via the gsc_wait_t structure's flags field having the GSC_WAIT_FLAG_TIMEOUT flag set, rather than via an ETIMEDOUT error.

Usage

Argument	Description
request	AISS8AO8_IOCTL_WAIT_EVENT
arg	gsc_wait_t*

Definition

```
typedef struct
{
    u32  flags;
    u32  main;
    u32  gsc;
    u32  alt;
    u32  io;
    u32  timeout_ms;
    u32  count;
} gsc_wait_t;
```

Fields	Description
flags	This must initially be zero. Upon return this indicates the reason that the thread was resumed. Refer to section 4.7.76.1 on page 52.
main	This specifies any number of GSC_WAIT_MAIN_* events that the thread is to wait for. Refer to section 4.7.76.2 on page 52.
gsc	This is unused by the 18AISS8AO8 driver and must be zero.
alt	This is unused by the 18AISS8AO8 driver and must be zero.
io	This specifies any number of GSC_WAIT_IO_* events that the thread is to wait for. Refer to section 4.7.76.4 on page 53.
timeout_ms	This specified the maximum amount of time, in milliseconds, that the thread is to wait for any of the referenced events. A value of zero means do not timeout at all. If non-zero, then upon return the value will be the approximate amount of time actually waited.
count	This is unused by wait event operations and must be zero.

4.7.76.1. `gsc_wait_t.flags` Options

Upon return from a wait request the wait structure's `flags` field will indicate the reason that the thread was resumed. Only one of the below options will be set.

Fields	Description
<code>GSC_WAIT_FLAG_CANCEL</code>	The wait request was cancelled.
<code>GSC_WAIT_FLAG_DONE</code>	One of the referenced events occurred.
<code>GSC_WAIT_FLAG_TIMEOUT</code>	The timeout period lapsed before a referenced event occurred.

4.7.76.2. `gsc_wait_t.main` Options

The wait structure's `main` field may specify any of the below primary interrupt options. These interrupt options are supported by the 18AISS8AO8 and other General Standards products.

Fields	Description
<code>GSC_WAIT_MAIN_DMA0</code>	This refers to the DMA Done interrupt on DMA engine number zero.
<code>GSC_WAIT_MAIN_DMA1</code>	This refers to the DMA Done interrupt on DMA engine number one.
<code>GSC_WAIT_MAIN_GSC</code>	This refers to any of the Interrupt Control/Status Register interrupts.
<code>GSC_WAIT_MAIN_OTHER</code>	This generally refers to an interrupt generated by another device sharing the same interrupt as the 18AISS8AO8.
<code>GSC_WAIT_MAIN_PCI</code>	This refers to any interrupt generated by the 18AISS8AO8.
<code>GSC_WAIT_MAIN_SPURIOUS</code>	This refers to board interrupts which should never be generated.
<code>GSC_WAIT_MAIN_UNKNOWN</code>	This refers to board interrupts whose source could not be identified.

4.7.76.3. `gsc_wait_t.gsc` Options

The wait structure's `gsc` field may specify any of the below firmware interrupt options.

Value	Description
-1	Retrieve the current setting.
<code>AISS8AO8_WAIT_GSC_AI_CLOCK</code>	This refers to the analog input clock.
<code>AISS8AO8_WAIT_GSC_AI_BURST_DONE</code>	This refers to the completion of an analog input burst.
<code>AISS8AO8_WAIT_GSC_AI_BURST_START</code>	This refers to the beginning of an analog input burst.
<code>AISS8AO8_WAIT_GSC_AI_FAULT</code>	This refers to an input buffer overflow or underflow.
<code>AISS8AO8_WAIT_GSC_AI_THRESH_H2L</code>	This refers to a low to high transition of the analog input threshold level status.
<code>AISS8AO8_WAIT_GSC_AI_THRESH_L2H</code>	This refers to a high to low transition of the analog input threshold level status.
<code>AISS8AO8_WAIT_GSC_AO_BURST_READY</code>	This refers to readiness of the board to begin an analog output burst.
<code>AISS8AO8_WAIT_GSC_AO_CLOCK</code>	this refers to the analog output clock.
<code>AISS8AO8_WAIT_GSC_AO_FAULT</code>	This refers to an analog output buffer underflow, or to a data or frame overflow.
<code>AISS8AO8_WAIT_GSC_AO_LOAD_RDY_HL</code>	This refers to a high to low transition of the output buffer's Load Ready status.
<code>AISS8AO8_WAIT_GSC_AO_LOAD_RDY_LH</code>	This refers to a low to high transition of the output buffer's Load Ready status.
<code>AISS8AO8_WAIT_GSC_AO_THRESH_H2L</code>	This refers to a high to low transition of the output buffer's threshold level status.
<code>AISS8AO8_WAIT_GSC_AO_THRESH_L2H</code>	This refers to a low to high transition of the output buffer's threshold level status.
<code>AISS8AO8_WAIT_GSC_AUTO_CAL_DONE</code>	This refers to the completion of an auto-calibration cycle.
<code>AISS8AO8_WAIT_GSC_DIO_0_L2H</code>	This refers to a low to high transition at digital I/O signal D0.

4.7.76.4. gsc_wait_t.io Options

The wait structure's io field may specify any of the below event options. These events are generated in response to application board data read requests.

Fields	Description
AISS8AO8 WAIT IO RX ABORT	This refers to read requests which have been aborted.
AISS8AO8 WAIT IO RX DONE	This refers to read requests which have been satisfied.
AISS8AO8 WAIT IO RX ERROR	This refers to read requests which end due to an error.
AISS8AO8 WAIT IO RX TIMEOUT	This refers to read requests which end due to the timeout period lapse.
AISS8AO8 WAIT IO TX ABORT	This refers to write requests which have been aborted.
AISS8AO8 WAIT IO TX DONE	This refers to write requests which have been satisfied.
AISS8AO8 WAIT IO TX ERROR	This refers to write requests which end due to an error.
AISS8AO8 WAIT IO TX TIMEOUT	This refers to write requests which end due to the timeout period lapse.

4.7.77. AISS8AO8_IOCTL_WAIT_STATUS

This service counts all threads blocked via the AISS8AO8_IOCTL_WAIT_EVENT IOCTL service (section 4.7.76, page 51), according to the provided criteria. A match is made when a waiting thread's wait criteria matches any of the criteria specified in the structure passed to this service.

NOTE: The driver itself makes use of the wait services for various internal operations. Driver initiated waits are ignored by application status requests.

Usage

Argument	Description
request	AISS8AO8_IOCTL_WAIT_STATUS
arg	gsc_wait_t*

Definition

```
typedef struct
{
    u32  flags;
    u32  main;
    u32  gsc;
    u32  alt;
    u32  io;
    u32  timeout_ms;
    u32  count;
} gsc_wait_t;
```

Fields	Description
flags	This is unused by wait status operations.
main	This specifies the set of GSC_WAIT_MAIN_* events whose wait requests are to be counted. Refer to section 4.7.76.2 on page 52.
gsc	This specifies the set of AISS8AO8_WAIT_GSC_* events whose wait requests are to be counted. Refer to section 4.7.76.3 on page 52.
alt	This is unused by the 18AISS8AO8 driver and should be zero.
io	This specifies the set of GSC_WAIT_IO_* events whose wait requests are to be counted. Refer to section 4.7.76.4 on page 53.
timeout_ms	This is unused by wait status operations.
count	Upon return this indicates the number of waits that met any of the specified criteria.

4.7.78. AISS8AO8_IOCTL_WARP_MODE

This service enables or disables the Warp mode feature associated with the input sampling rate.

Usage

Argument	Description
request	AISS8AO8_IOCTL_WARP_MODE
arg	s32*

Valid argument values are as follows.

Value	Description
-1	Retrieve the current setting.
AISS8AO8_WARP_MODE_DISABLE	This option disables Warp mode.
AISS8AO8_WARP_MODE_ENABLE	This option enables Warp mode.

5. The Driver

NOTE: Contact General Standards Corporation if additional driver functionality is required.

5.1. Files

The device driver files are summarized in the table below.

File	Description
driver/*.c	The driver source files.
driver/*.h	The driver header files.
driver/18aiiss8ao8.h	This is the driver interface header file.
driver/Makefile	This is the driver make file.
driver/start	Shell script to install the driver executable and device nodes.
driver/18aiiss8ao8.ko	This is the driver executable (kernel 2.6 and later).
driver/18aiiss8ao8.o	This is the driver executable (kernel 2.4 and earlier).

5.2. Build

NOTE: Building the driver requires installation of the kernel headers.

The device driver is built via the Overall Make Script (section 2.7, page 13), but can be built separately following the below steps.

1. Change to the directory where the driver and its sources are installed (.../driver/).
2. Remove existing build targets by issuing the below command.

```
make clean
```

3. Build the driver by issuing the below command.

```
make
```

NOTE: Due to the differences between the many Linux distributions some build errors may occur. These errors may include system header location differences, which should be easily corrected.

5.3. Startup

NOTE: The driver will have to be built before being used as it is provided in source form only.

The startup script used in this procedure is designed to ensure that the driver module in the install directory is the module that is loaded. This is accomplished by making sure that an already loaded module is first unloaded before attempting to load the module from the disk drive. In addition, the script also deletes and recreates the device nodes. This is done to ensure that the device nodes in use have the same major number as assigned dynamically to the driver by the kernel, and so that the number of device nodes correspond to the number of boards identified by the driver.

5.3.1. Manual Driver Startup Procedures

Start the driver manually by following the below listed steps.

NOTE: The following steps may require elevated privileges.

1. Change to the directory where the driver sources are installed (.../driver/).
2. Install the driver module and create the device nodes by executing the below command. If any errors are encountered then an appropriate error message will be displayed.

```
./start
```

NOTE: This script must be executed each time the host is rebooted.

NOTE: The 18AISS8AO8 device node major number is assigned dynamically by the kernel. The minor numbers and the device node suffix numbers are index numbers beginning with zero, and increase by one for each additional board installed.

3. Verify that the device driver module has been loaded by issuing the below command and examining the output. The module name `18aiiss8ao8` should be included in the output.

```
lsmod
```

4. Verify that the device nodes have been created by issuing the below command and examining the output. The output should include one node for each installed board.

```
ls -l /dev/18aiiss8ao8.*
```

5.3.2. Automatic Driver Startup Procedures

Start the driver automatically with each system reboot by following the below listed steps.

1. Locate and edit the system startup script `rc.local`, which should be in the `/etc/rc.d/` directory. Modify the file by adding the below line so that it is executed with every reboot. The example is based on the driver being installed in `/usr/src/linux/drivers/`, though it may have been installed elsewhere.

```
/usr/src/linux/drivers/18aiiss8ao8/driver/start
```

NOTE: For `systemd` installations the file `rc.local` may be located under the `/etc/` directory rather than under `/etc/rc.d/`.

2. Load the driver and create the required device nodes by rebooting the system.
3. Verify that the driver is loaded and that the device nodes have been created. Do this by following the verification steps given in the manual startup procedures.

5.3.2.1. File `rc.local` Not Present

Some distributions may not install a default version of `rc.local`. Some may not even create the directory `/etc/rc.d/`. If the directory is not present, then it may be created. The directory must be created with the owner and group set to `root`. The directory permissions must be set to `rwxr-xr-x`. If the file `/etc/rc.d/rc.local` is not present, then it too may be created. The file must also be created with the owner and group set to `root`. Additionally, the file permissions must also be set to `rwxr-xr-x`. After the directory and file are created as described, reboot to verify boot time loading of the driver. Here is an example of a default version of `rc.local`.

```
#!/bin/bash
# Add you local content here.
```

5.3.2.2. Default `rc.local` File Permissions

The `rc.local` script may fail to run at boot time because some distributions install a default version of the file without execute permissions. Without execute permissions, boot time invocation of the script fails, which inhibits boot time loading of the driver. If this is the case, then change the file permissions to `rwxr-xr-x`. After the file permissions are adjusted as described, reboot to verify boot time loading of the driver.

5.3.2.3. `systemd` Installations

With the advent of the `systemd` startup implementation, `rc.local` may be accessed via a `systemd` startup service. The service name may be `rc-local`, `rc-local.service` or something similar. This service may or may not be enabled by default. If the service is disabled, then the script will not execute, which prevents boot time loading of the driver. The service can be enabled with the below command line. After the service is enabled, reboot to verify boot time loading of the driver.

```
systemctl enable rc-local
```

NOTE: For `systemd` installations the file `rc.local` may be located under the `/etc/` directory rather than under `/etc/rc.d/`.

5.3.2.4. `systemd` and `rc.local` Timing

If the above steps have been performed but the driver still does not start then examine the `dmesg` output for driver messages. If the output shows that the driver starts and immediately stops, then the problem may be timing. That is, since `systemd` doesn't serialize startup initialization as done in the past, driver loading may fail if required services have not completed their own initialization. If this is the problem, then it may be corrected simply by inserting a delay in `rc.local` prior to it calling the driver's start script (i.e., `sleep` for one or more seconds).

5.3.2.5. SELinux Implications

If not disabled, then SELinux may prevent boot time loading of the driver. If this is the case, then it can be verified and corrected using SELinux related tools and utilities. First, install the necessary software using the below command. (As necessary, replace the `yum` command line with that which is available for your distribution.)

```
yum install setroubleshoot setools
```

Next, run the below command to determine if SELinux is preventing the driver from loading at boot time.

```
sealert -a /var/log/audit/audit.log
```

If SELinux is preventing the driver from loading, then the output from the above command should include a reference to the driver's start script, the `insmod` command that loads the driver or the name of the driver executable. If so, then the output should also indicate the commands necessary to resolve the issue. The following is an example of the instructions given when the culprit is `insmod`, which is the start script command that loads the driver. After running these commands reboot the system to verify boot time loading of the driver.

```
ausearch -c 'insmod' --raw | audit2allow -M my-insmod
semodule -X 300 -i my-insmod.pp
```

5.4. Verification

Follow the below steps to verify that the driver has been properly installed and started.

1. Verify that the file `/proc/18aiiss8ao8` is present. If the file is present then the driver is loaded and running. Verify the file's presence by viewing its content with the below command.

```
cat /proc/18aiiss8ao8
```

5.5. Version

The driver version number can be obtained in a variety of ways. It is reported by the driver both when the driver is loaded and when it is unloaded (depending on kernel configuration options, this may be visible only in places such as `/var/log/messages`). It is reported in the text file `/proc/18aiiss8ao8` while the driver is loaded and running. The version number is also given in the file `release.txt` in the root install directory.

5.6. Shutdown

Shutdown the driver following the below listed steps.

NOTE: The following steps may require elevated privileges.

1. If the driver is currently loaded then issue the below command to unload the driver.

```
rmmod 18aiiss8ao8
```

2. Verify that the driver module has been unloaded by issuing the below command. The module name `18aiiss8ao8` should not be in the listed output.

```
lsmod
```

6. Document Source Code Examples

The source code examples included in this document are built into a statically linkable library usable with console applications. The purpose of these files is to verify that the documentation samples compile and to provide a library of working sample code to assist in a user's learning curve and application development effort.

6.1. Files

The library files are summarized in the table below.

File	Description
docsrc/*.c	These are the C source files.
docsrc/makefile	This is the library make file.
docsrc/makefile.dep	This is an automatically generated make dependency file.
include/18aiiss8ao8_dsl.h	This is the primary utility header file.
lib/18aiiss8ao8_dsl.a	This is the statically linkable library file.

6.2. Build

The library is built via the Overall Make Script (section 2.7, page 13), but can be built separately following the below steps.

1. Change to the directory where the documentation sources are installed (.../docsrc/).

2. Remove existing build targets by issuing the below command.

```
make clean
```

3. Compile the sample files and build the library by issuing the below command.

```
make
```

4. Rebuild the Main Library (section 3.2.1, page 16).

6.3. Library Use

The library is used both at application compile time and at application link time. At compile time include the below listed header file in each source file using a component of the library interface. At link time include the below listed library file with the objects being linked with the application.

Description	File	Location
Header File	18aiiss8ao8_dsl.h	.../include/
Static Link Library	18aiiss8ao8_dsl.a	.../lib/

7. Utility Source Code

The driver archive includes a body of utility services built into a statically linkable library that is usable with console applications. The primary purpose of the services is both for code reuse in the sample applications and to provide wrappers, mostly visual, around the driver's IOCTL services. The aim of the visual wrappers is to facilitate structured console output for the sample applications. An additional purpose of these utility services is to provide a library of working sample code to assist in a user's learning curve and application development effort.

7.1. Files

The library files are summarized in the table below.

File	Description
utils/*.c	These are device specific utility source files.
utils/gsc_*.c	These are device and OS independent utility source files.
utils/os_*.c	These are OS specific utility source files.
utils/makefile	This is the library make file.
utils/makefile.dep	This is an automatically generated make dependency file.
include/18aiss8ao8_utils.h	This is the primary utility header file.
lib/18aiss8ao8_utils.a	This is the statically linkable library file.

7.2. Build

The library is built via the Overall Make Script (section 2.7, page 13), but can be built separately following the below steps.

1. Change to the directory where the utility sources are installed (.../utils/).
2. Remove existing build targets by issuing the below command.

```
make clean
```

3. Compile the sample files and build the library by issuing the below command.

```
make
```

4. Rebuild the Main Library (section 3.2.1, page 16).

7.3. Library Use

The library is used both at application compile time and at application link time. At compile time include the below listed header file in each source file using a component of the library interface. At link time include the below listed library files with the objects being linked with the application.

Description	File	Location
Header File	18aiss8ao8_utils.h	.../include/
Static Link Libraries	18aiss8ao8_utils.a gsc_utils.a os_utils.a plx_utils.a	.../lib/

8. Operating Information

This section explains some basic operational procedures for using the 18AISS8AO8. This is in no way intended to be a comprehensive guide. This is simply to address a very few issues relating to their use.

8.1. Debugging Aids

The driver package includes the following items useful for development and/or debugging aids.

8.1.1. Device Identification

When communicating with technical support complete device identification is virtually always necessary. The *id* example application is provided for this specific purpose. This is a text only console application. The output can be piped to a file, which can then be emailed to GSC technical support when requested. Locate the application as follows.

Description	File	Location
Application	id	.../id/

8.1.2. Detailed Register Dump

Among the utility services provided is a function to generate a detailed listing of the board's registers to the console. When used, the function is typically used to verify the board's configuration. In these cases, the function should be called just prior to the first read or write operation. When intended for sending to GSC tech support, please set the *detail* argument to 1. The function arguments are as follows. The utility location is given in the subsequent table.

Argument	Description
fd	This is the file descriptor used to access the device.
detail	If non-zero the GSC register dump will include details of each register field.

Description	File/Name	Location
Function	aiss8ao8_reg_list()	Source File
Source File	reg.c	.../utils/
Header File	18aiss8ao8_utils.h	.../include/
Library File	18aiss8ao8_utils.a	.../lib/

8.2. Analog Input Configuration

The basic steps for Analog Input configuration are illustrated in the utility function noted below. The table also gives the location of the source file, the header file and the corresponding library containing the executable code.

Item	Name/File	Location
Function	aiss8ao8_config_ai()	Source File
Source File	config_ai.c	.../utils/
Header File	18aiss8ao8_utils.h	.../include/
Library File	18aiss8ao8_utils.a	.../lib/

8.3. Analog Output Configuration

The basic steps for Analog Output configuration are illustrated in the utility function noted below. The table also gives the location of the source file, the header file and the corresponding library containing the executable code.

Item	Name/File	Location
Function	aiss8ao8_config_ao()	Source File
Source File	config_ao.c	.../utils/
Header File	18aiss8ao8_utils.h	.../include/
Library File	18aiss8ao8_utils.a	.../lib/

8.4. I/O Modes

8.4.1. PIO - Programmed I/O

This mode involves repetitive register accesses. This is most applicable for low throughput requirements or for small transfer requests. The driver will transfer data between host memory and the board's buffer register until the transfer is complete or the I/O timeout expires, whichever occurs first. This is generally the least efficient mode, but for very small transfers it is more efficient than DMA.

8.4.2. BMDMA - Block Mode DMA

This mode is intended for data transfers that do not exceed the size of the 18AISS8AO8 input/output buffer. Here, the board's DMA engine is used to perform a hardware-controlled transfer which does not require processor intervention to move the data. In this mode the DMA read transfer is initiated only when the input buffer contains sufficient data to fulfill the request. For write requests a DMA transfer is initiated only when the output buffer contains sufficient space to fulfill the request. This is a very efficient I/O method. However, for small requests PIO is more efficient.

8.4.3. DMDMA - Demand Mode DMA

This DMA transfer mode is similar to the block mode, except that a transfer for the entire amount of data is initiated immediately and is not limited to the size of the board's FIFO. Here however, the actual movement of data occurs as the data becomes available in the input buffer, for reads, or as space becomes available in the output buffer, for writes. This is the most efficient method supported. However, for small requests PIO is more efficient.

9. Sample Applications

The driver archive includes a variety of sample and test applications. While they are provided without support and without any external documentation, any problems reported will be addressed as time permits. The applications are command line based and produce text output for display on a console. All of the applications are built via the Overall Make Script (section 2.7, page 13), but each may be built individually by changing to its respective directory and issuing the commands “make clean” and “make all”. The initial output from each application includes information on its supported command line arguments. The following gives a brief overview of each application.

9.1. aout - Analog Output - .../aout/

This application outputs a repeating pattern on the four output channels. The pattern is different for each channel, though they are synchronized at the same modest rate.

9.2. din - Digital Input - .../din/

This application reads the cable’s digital I/O signals and reports the values read to the console.

9.3. dout - Digital Output - .../dout/

This application writes a pattern to the cable’s digital output lines as it is displayed to the console.

9.4. fsamp - Sample Rate - .../fsamp/

This application reports the device configuration required to produce a user specified sample rate.

9.5. id - Identify Board - .../id/

This application reports detailed board identification information. This can be used with tech support to help identify as much technical information about the board as possible from software.

9.6. regs - Register Access - .../regs/

This application provides menu based interactive access to the board’s registers, and reports other pertinent information to the console.

9.7. rxrate - Receive Rate - .../rxrate/

This application configures the board for its highest ADC sample rate then reads the input as fast as possible. The purpose is to measure the peak sustainable input rate for the host, per the provided command line arguments.

9.8. savedata - Save Acquired Data - .../savedata/

This application configures the board for a modest sample rate, reads a megabyte of data, then saves the data to a hex file.

9.9. signals - Digital Signals - .../signals/

This application configures the board to drive the digital output signals for a user specified period of time. This is done to facilitate setup of test equipment to capture those signals during actual use.

9.10. txrate - Transmit Rate - .../txrate/

This application configures the board for its highest output sample rate then writes output as fast as possible. The purpose is to measure the peak sustainable output rate for the host, per the provided command line arguments.

Document History

Revision	Description
April 21, 2023	Updated to release version 1.4.102.45.1.
March 10, 2023	Updated to release version 1.4.102.45.0. Updated the kernel support table. Minor editorial updates. Added sample applications <code>fsamp</code> , <code>rxrate</code> and <code>txrate</code> .
October 26, 2022	Updated to release version 1.3.101.44.0. Updated the kernel support table. Added section on environment variables. Updated the information for the open and close calls. Numerous minor editorial modifications.
February 17, 2022	Updated to release version 1.2.96.38.0. Updated the kernel support table. Minor editorial changes. Expanded automatic startup information.
September 12, 2019	Updated to release version 1.1.87.28.0. Updated the kernel support table. Minor editorial changes. Added support for the input buffer underflow feature (AISS8AO8_QUERY_AI_UNDERFLOW, AISS8AO8_IOCTL_RX_IO_UNDERFLOW and AISS8AO8_IOCTL_AI_BUF_UNDERFLOW). Added a licensing subsection. Added WAIT_EVENT note.
April 4, 2019	Initial release, version 1.0.84.27.0.